

# User Manual

## PV Grid-Connected Inverter

SG25CX-P2 / SG30CX-P2 / SG33CX-P2 / SG36CX-P2 /  
SG40CX-P2 / SG50CX-P2





# All Rights Reserved

## **All Rights Reserved**

No part of this document can be reproduced in any form or by any means without the prior written permission of Sungrow Power Supply Co., Ltd (hereinafter "SUNGROW").

## **Trademarks**

**SUNGROW** and other Sungrow trademarks used in this manual are owned by SUNGROW.

All other trademarks or registered trademarks mentioned in this manual are owned by their respective owners.

## **Software Licenses**

- It is prohibited to use data contained in firmware or software developed by SUNGROW, in part or in full, for commercial purposes by any means.
- It is prohibited to perform reverse engineering, cracking, or any other operations that compromise the original program design of the software developed by SUNGROW.

# About This Manual

The manual mainly contains the product information, as well as guidelines for installation, operation, and maintenance. The manual does not include complete information about the photovoltaic (PV) system. Readers can get additional information at [www.sungrowpower.com](http://www.sungrowpower.com) or on the webpage of the respective component manufacturer.

## Validity

This manual is valid for the following model of low-power grid-connected PV string inverters:

- SG25CX-P2
- SG30CX-P2
- SG33CX-P2
- SG36CX-P2
- SG40CX-P2
- SG50CX-P2

It will be referred to as "inverter" hereinafter unless otherwise specified.

## Target Group

This manual is intended for professional technicians who are responsible for installation, operation, and maintenance of inverters, and users who need to check inverter parameters.

The inverter must only be installed by professional technicians. The professional technician is required to meet the following requirements:

- Know electronic, electrical wiring and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Have received professional training related to the installation and commissioning of electrical equipment.
- Be able to quickly respond to hazards or emergencies that occur during installation and commissioning.
- Be familiar with local standards and relevant safety regulations of electrical systems.
- Read this manual thoroughly and understand the safety instructions related to operations.

## How to Use This Manual

Please read this manual carefully before using the product and keep it properly at a place for easy access.

All contents, pictures, marks, and symbols in this manual are owned by SUNGROW. No part of this document may be reprinted by the non-internal staff of SUNGROW without written authorization.



Contents of this manual may be periodically updated or revised, and the actual product purchased shall prevail. Users can obtain the latest manual from [support.sungrowpower.com](https://support.sungrowpower.com) or sales channels.

## **Symbols**

This manual contains important safety instructions, which are highlighted with the following symbols, to ensure personal and property safety during usage, or to help optimize the product performance in an efficient way.

Please carefully understand the meaning of these warning symbols to better use the manual.

### **DANGER**

**Indicates high-risk potential hazards that, if not avoided, may lead to death or serious injury.**

### **WARNING**

**Indicates moderate-risk potential hazards that, if not avoided, may lead to death or serious injury.**

### **CAUTION**

**Indicates low-risk potential hazards that, if not avoided, may lead to minor or moderate injury.**

### **NOTICE**

**Indicates potential risks that, if not avoided, may lead to device malfunctions or financial losses.**



“NOTE” indicates additional information, emphasized contents or tips that may be helpful, e.g., to help you solve problems or save time.



# Contents

---

|                                          |           |
|------------------------------------------|-----------|
| All Rights Reserved .....                | I         |
| About This Manual .....                  | II        |
| <b>1 Safety Instructions .....</b>       | <b>1</b>  |
| 1.1 Unpacking and Inspection .....       | 2         |
| 1.2 Installation Safety .....            | 2         |
| 1.3 Electrical Connection Safety .....   | 3         |
| 1.4 Operation Safety .....               | 4         |
| 1.5 Maintenance Safety .....             | 5         |
| 1.6 Disposal Safety .....                | 6         |
| <b>2 Product Description .....</b>       | <b>7</b>  |
| 2.1 System Introduction .....            | 7         |
| 2.2 Product Introduction .....           | 8         |
| 2.3 Symbols on Product .....             | 10        |
| 2.4 LED Indicator .....                  | 11        |
| 2.5 Circuit Diagram .....                | 12        |
| 2.6 Function Description .....           | 13        |
| <b>3 Unpacking and Storage .....</b>     | <b>16</b> |
| 3.1 Unpacking and Inspection .....       | 16        |
| 3.2 Inverter Storage .....               | 16        |
| <b>4 Mechanical Mounting .....</b>       | <b>18</b> |
| 4.1 Safety During Mounting .....         | 18        |
| 4.2 Location Requirements .....          | 19        |
| 4.2.1 Environment Requirements .....     | 19        |
| 4.2.2 Carrier Requirements .....         | 20        |
| 4.2.3 Angle Requirements .....           | 20        |
| 4.2.4 Clearance Requirements .....       | 21        |
| 4.3 Installation Tools .....             | 23        |
| 4.4 Moving the Inverter .....            | 24        |
| 4.5 Installing Mounting-bracket .....    | 25        |
| 4.5.1 Bracket-Mounted Installation ..... | 25        |
| 4.5.2 Wall-Mounted Installation .....    | 26        |

|                                                                 |           |
|-----------------------------------------------------------------|-----------|
| 4.5.3 Pole Installation .....                                   | 27        |
| 4.6 Installing the Inverter.....                                | 29        |
| <b>5 Electrical Connection .....</b>                            | <b>31</b> |
| 5.1 Safety Instructions .....                                   | 31        |
| 5.2 Terminal Description .....                                  | 33        |
| 5.3 Electrical Connection Overview .....                        | 34        |
| 5.4 Crimp OT/DT terminal .....                                  | 36        |
| 5.5 External Protective Grounding Connection .....              | 37        |
| 5.5.1 External Protective Grounding Requirements .....          | 38        |
| 5.5.2 Connection Procedure .....                                | 38        |
| 5.6 AC Cable Connection .....                                   | 39        |
| 5.6.1 AC Side Requirements .....                                | 39        |
| 5.6.2 Requirements for OT/DT Terminal .....                     | 40        |
| 5.6.3 Connection Procedure .....                                | 40        |
| 5.7 DC Cable Connection .....                                   | 44        |
| 5.7.1 PV Input Configuration .....                              | 46        |
| 5.7.2 Assembling PV Connectors .....                            | 47        |
| 5.7.3 Installing PV Connector .....                             | 49        |
| 5.8 Communication Connection .....                              | 50        |
| 5.8.1 Wireless Communication Module Connection (optional) ..... | 50        |
| 5.8.2 WiNet-S Connection (optional) .....                       | 50        |
| 5.8.2.1 Ethernet Communication .....                            | 51        |
| 5.8.2.2 WLAN Communication .....                                | 52        |
| 5.8.3 RS485 Connection .....                                    | 53        |
| 5.8.3.1 Assembling the COM Connector .....                      | 54        |
| 5.8.3.2 Installing the COM Connector .....                      | 55        |
| 5.8.4 Smart Energy Meter Connection .....                       | 56        |
| 5.8.5 Dry Contact Connection .....                              | 57        |
| 5.8.5.1 Dry Contact Function .....                              | 57        |
| 5.8.5.2 Wiring Procedure .....                                  | 57        |
| 5.8.6 DRM Connection .....                                      | 58        |
| 5.8.6.1 Assembling the COM Connector .....                      | 59        |
| 5.8.6.2 Installing the COM Connector .....                      | 61        |
| <b>6 Commissioning .....</b>                                    | <b>62</b> |
| 6.1 Inspection Before Commissioning .....                       | 62        |
| 6.2 Commissioning Procedure .....                               | 62        |

|                                             |     |
|---------------------------------------------|-----|
| 7 iSolarCloud App .....                     | 64  |
| 7.1 Brief Introduction .....                | 64  |
| 7.2 Installing App .....                    | 64  |
| 7.3 Login .....                             | 65  |
| 7.3.1 Requirements .....                    | 65  |
| 7.3.2 Login Procedure .....                 | 65  |
| 7.4 Function Overview .....                 | 70  |
| 7.5 Home .....                              | 70  |
| 7.6 Run Information .....                   | 72  |
| 7.7 Records .....                           | 74  |
| 7.8 More .....                              | 76  |
| 7.8.1 System Parameters .....               | 76  |
| 7.8.2 Operation Parameters .....            | 77  |
| 7.8.3 Power Regulation Parameters .....     | 79  |
| 7.8.4 Communication Parameters .....        | 84  |
| 7.8.5 Firmware Update .....                 | 84  |
| 7.8.6 Grounding Detection .....             | 85  |
| 7.8.7 Password Changing .....               | 86  |
| 8 System Decommissioning .....              | 87  |
| 8.1 Disconnecting Inverter .....            | 87  |
| 8.2 Dismantling the Inverter .....          | 87  |
| 8.3 Disposal of Inverter .....              | 88  |
| 9 Troubleshooting and Maintenance .....     | 89  |
| 9.1 Troubleshooting .....                   | 89  |
| 9.2 Maintenance .....                       | 98  |
| 9.2.1 Maintenance Notices .....             | 98  |
| 9.2.2 Routine Maintenance .....             | 99  |
| 9.2.3 Cleaning Air Inlet and Outlet .....   | 100 |
| 9.2.4 Fan Maintenance .....                 | 100 |
| 10 Appendix .....                           | 102 |
| 10.1 Technical Data .....                   | 102 |
| 10.2 Wring Distance of DI Dry Contact ..... | 112 |
| 10.3 Quality Assurance .....                | 114 |
| 10.4 Contact Information .....              | 114 |



# 1 Safety Instructions

When installing, commissioning, operating, and maintaining the product, strictly observe the labels on the product and the safety requirements in the manual. Incorrect operation or work may cause:

- Injury or death to the operator or a third party.
- Damage to the product and other properties.

## WARNING

- **Do not operate the product and cables (including but not limited to moving the product, installing the product, operating the product and cables, powering up the product, maintaining the product, and working at heights) in harsh weather conditions such as flooding, lightning, rain, snow, and level 6 or stronger wind.**
- **In case of fire, evacuate from the building or product area and call the fire alarm. Re-entry into the burning area is strictly prohibited under any circumstances.**

## NOTICE

- **Tighten the screws with the specified torque using tools when fastening the product and terminals. Otherwise, the product may be damaged. And the damage caused is not covered by the warranty.**
- **Learn how to use tools correctly before using them to avoid hurting people or damaging the device.**
- **Maintain the device with sufficient knowledge of this manual and use proper tools.**



- The safety instructions in this manual are only supplements and cannot cover all the precautions that should be followed. Perform operations considering actual onsite conditions.
- SUNGROW shall not be held liable for any damage caused by violation of general safety operation requirements, general safety standards, or any safety instruction in this manual.
- When installing, operating, and maintaining the product, comply with local laws and regulations. The safety precautions in this manual are only supplements to local laws and regulations.

## 1.1 Unpacking and Inspection

### WARNING

- Check all safety signs, warning labels and nameplates on devices.
- The safety signs, warning labels and nameplates must be clearly visible and cannot be removed or covered before the device is decommissioned.

### NOTICE

After receiving the product, check whether the appearance and structural parts of the device are damaged, and check whether the packing list is consistent with the actual ordered product. If there are problems with the above inspection items, do not install the device and contact your distributor first. If the problem persists, contact SUNGROW in time.

## 1.2 Installation Safety

### DANGER

- Make sure there is no electrical connection before installation.
- Before drilling, avoid the water and electricity wiring in the wall.

### CAUTION

Improper installation may cause personal injury!

- If the product supports hoisting transport and is hoisted by hoisting tools, no one is allowed to stay under the product.
- When moving the product, be aware of the product weight and keep the balance to prevent it from tilting or falling.

### NOTICE

Before operating the product, must check and ensure that tools to be used have been maintained regularly.



## 1.3 Electrical Connection Safety

### DANGER

- Before electrical connections, please make sure that the inverter is not damaged, otherwise it may cause danger!
- Before electrical connections, please make sure that the inverter switch and all switches connected to the inverter are set to "OFF", otherwise electric shock may occur!

### DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

- Operators must wear proper personal protective equipment during electrical connections.
- Must ensure that cables are voltage-free with a measuring instrument before touching DC cables.
- Respect all safety instructions listed in relevant documents about PV strings.
- The inverter must not be connected to a PV string that requires positive or negative grounding.

### DANGER

Danger to life due to a high voltage inside the inverter!

- Be sure to use special insulation tools during cable connections.
- Note and observe the warning labels on the product, and perform operations strictly following the safety instructions.
- Respect all safety instructions listed in this manual and other pertinent documents.

### WARNING

Damage to the product caused by incorrect wiring is not covered by the warranty.

- Electrical connection must be performed by professionals.
- All cables used in the PV generation system must be firmly attached, properly insulated, and adequately dimensioned.

**⚠ WARNING**

- Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness.
- During the installation and operation of the inverter, please ensure that the positive or negative poles of PV strings do not short-circuit to the ground. Otherwise, an AC or DC short-circuit may occur, resulting in equipment damage. The damage caused by this is not covered by the warranty.

**NOTICE**

Comply with the safety instructions related to PV strings and the regulations related to the local grid.

## 1.4 Operation Safety

**⚠ DANGER**

When routing cables, ensure a distance of at least 30 mm between the cables and heat-generating components or areas to protect the insulation layer of cables from aging and damage.

When the product is working:

- Do not touch the product enclosure.
- It is strictly forbidden to plug and unplug any connector on the inverter.
- Do not touch any wiring terminal of the inverter. Otherwise, electric shock may occur.
- Do not disassemble any parts of the inverter. Otherwise, electric shock may occur.
- It is strictly forbidden to touch any hot parts of the inverter (such as the heat sink). Otherwise, it may cause burns.
- Do not connect or remove any PV string or any PV module in a string. Otherwise, electric shock may occur.
- If the inverter is equipped with a DC switch, do not operate it. Otherwise, it may cause device damage or personal injury.

## 1.5 Maintenance Safety

### DANGER

**Risk of inverter damage or personal injury due to incorrect service!**

- Before maintenance, disconnect the AC circuit breaker on the grid side and then the DC switch. If a fault that may cause personal injury or device damage is found before maintenance, disconnect the AC circuit breaker and wait until the night before operating the DC switch. Otherwise, a fire inside the product or an explosion may occur, causing personal injuries.
- After the inverter is powered off for 15 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

### DANGER

**Touching the power grid or the contact points and terminals on the inverter connected to the power grid may lead to electric shock!**

- The power grid side may generate voltage. Always use a standard voltmeter to ensure that there is no voltage before touching.

### CAUTION

**To prevent misuse or accidents caused by unrelated personnel, post prominent warning signs or demarcate safety warning areas around the product.**

### NOTICE

**To avoid the risk of electric shock, do not perform any other maintenance operations beyond those described in this manual. If necessary, contact your distributor first. If the problem persists, contact SUNGROW. Otherwise, the losses caused is not covered by the warranty.**

**NOTICE**

- **If the paint on the inverter enclosure falls or rusts, repair it in time. Otherwise, the inverter performance may be affected.**
- **Do not use cleaning agents to clean the inverter. Otherwise, the inverter may be damaged, and the loss caused is not covered by the warranty.**
- **As the inverter contains no parts that can be maintained, never open the enclosure of the inverter or replace any internal components without authorization. Otherwise, the loss caused is not covered by the warranty.**

## 1.6 Disposal Safety

** WARNING**

**Please scrap the product in accordance with relevant local regulations and standards to avoid property losses or casualties.**

## 2 Product Description

### 2.1 System Introduction

The inverter is a transformerless 3-phase PV grid-connected inverter. As an integral component in the PV power system, the inverter is designed to convert the direct current power generated from the PV modules into grid-compatible AC current and to feed the AC current into the utility grid.

The intended usage of the inverter is illustrated in the following figure.




figure 2-1 Inverter Application in PV Power System

#### **WARNING**

**The inverter must not be connected to a PV string that requires positive or negative grounding.**

**Do not connect any local load between the inverter and the AC circuit breaker.**

#### **NOTICE**


**When designing the system, ensure that the operating ranges of all devices that are connected to the inverter meet the requirements of the inverter.**

**The PV modules in the system must comply with the IEC 61730-1 (2016) class II standard.**

**The inverter applies only to the scenarios described in this manual.**

| Item | Description             | Note                                                                              |
|------|-------------------------|-----------------------------------------------------------------------------------|
| A    | PV strings              | Monocrystalline silicon, polycrystalline silicon and thin-film without grounding. |
| B    | Inverter                | SG25CX-P2, SG30CX-P2, SG33CX-P2, SG36CX-P2, SG40CX-P2, SG50CX-P2                  |
| C    | Grid connection cabinet | Includes devices such as AC circuit breaker, SPD, metering device.                |

| Item | Description  | Note                                                                                          |
|------|--------------|-----------------------------------------------------------------------------------------------|
| D    | Transformer  | Raises the output voltage of the inverter to a level that meets the requirements of the grid. |
| E    | Utility grid | The grid forms supported by the inverter are shown in the figure below.                       |



#### NOTICE


In a TT power grid, the N-PE voltage should be lower than 30 V.

If the inverter is connected to the IT grid (i.e., no N line connection), there may be a risk of single-phase over/under-voltage and single-phase high/low voltage ride through.

## 2.2 Product Introduction

### Model Description


The model description is as follows (take SG30CX-P2 as an example):



S320-G002

## Appearance

The following figure shows the appearance of the inverter.



**figure 2-2** Appearance

The image shown here is for reference only. The actual product received may differ.

| No. | Name                                    | Description                                                                                                                 |
|-----|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| 1   | LED indicator                           | To indicate the current working state of the inverter.                                                                      |
| 2   | Mounting lugs                           | To hang the inverter onto the mounting-bracket.                                                                             |
| 3   | Handles                                 | To move the inverter.                                                                                                       |
| 4   | Labels                                  | To clearly identify the product, including Warning symbols, nameplate and QR code.                                          |
| 5   | External protective grounding terminals | Use to ground the inverter.                                                                                                 |
| 6   | DC switch                               | To safely disconnect the DC circuit whenever necessary.                                                                     |
| 7   | Wiring area                             | DC switches, DC terminals, and communication terminals.<br>For details, refer to <a href="#">"5.2 Terminal Description"</a> |

## Dimensions

The following figure shows the dimensions of the inverter.




figure 2-3 Product Dimensions(in mm)

**Weight**

| Model                    | Dimensions (W*H*D) | Weight |
|--------------------------|--------------------|--------|
| SG25/30/33CX-P2          | 645*575*245 mm     | 38 kg  |
| SG36/40CX-P2             |                    | 40 kg  |
| SG50CX-P2                |                    | 41 kg  |
| SG30CX-P2(For Australia) | 600*625*240 mm     | 35 kg  |
| SG50CX-P2(For Australia) |                    | 36 kg  |

**2.3 Symbols on Product**

| Symbol | Explanation                                                                                  |
|--------|----------------------------------------------------------------------------------------------|
|        | Do not dispose of the inverter together with household waste.                                |
|        | Read the user manual before maintenance!                                                     |
|        | TÜV mark of conformity.                                                                      |
|        | Regulatory compliance mark.                                                                  |
|        | CE mark of conformity.<br>EU/EEA Importer.                                                   |
|        | RoHS labeling<br>The product complies with the requirements of the applicable EU directives. |
|        | UKCA mark of conformity.                                                                     |



| Symbol                                                                                                                                                              | Explanation                                                                                                                                                                                |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                    | The inverter does not have a transformer.                                                                                                                                                  |
|                                                                                    | Disconnect the inverter from all the external power sources before maintenance!                                                                                                            |
|   | Danger to life due to high voltages!<br>Do not touch live parts for 15 minutes after disconnection from the power sources.<br>Only qualified personnel can open and maintain the inverter. |
|                                                                                    | External grounding point.                                                                                                                                                                  |


\* The table shown here is for reference only. The actual product received may differ.

## 2.4 LED Indicator

The LED indicator on the front of the inverter indicates the working state of the inverter.

table 2-1 LED Indicator State Description

| LED Color                                                                                   | State                                                                               | Definition                                                                   |
|---------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| <br>Blue | On                                                                                  | The device is connected to the grid and operating normally.                  |
|                                                                                             | Fast blink<br>(Period: 0.2s)                                                        | The Bluetooth connection is established, and there is data communication.    |
|                                                                                             |  | No system fault occurs.                                                      |
|                                                                                             | Slow blink<br>(Period: 2s)                                                          | The device is in standby or startup state (not feeding power into the grid). |
|                                                                                             |  |                                                                              |
|                                                                                             | Slow blink<br>once, fast<br>blink three<br>times                                    | The inverter is performing PID recovery.                                     |


| LED Color                                                                                 | State | Definition                                                                                         |
|-------------------------------------------------------------------------------------------|-------|----------------------------------------------------------------------------------------------------|
| <br>Red  | On    | A fault occurs and the device cannot connect to the grid.                                          |
|                                                                                           | Blink | The Bluetooth connection is established, data communication in process, and a system fault occurs. |
| <br>Gray | OFF   | Both the AC and DC sides are powered down.                                                         |

### ⚠ WARNING

**Voltage may still be present in AC side circuits after the indicator is off. Pay attention to the electricity safety when operating.**

## 2.5 Circuit Diagram

The following figure shows the main circuit of the inverter.



**figure 2-4** Circuit Diagram

- The DC Switch is used to safely disconnect the DC circuit.
- The MPPT is used to ensure a maximum power from PV arrays at different PV input conditions.
- The Inverter Circuit converts the DC power into AC power and feeds it to loads ( if there are ) or utility grid through the AC terminal.
- The protection circuit ensures the safe operation of the device and personal safety.

### ⚠ DANGER

**If the lightning level exceeds the protection level of the product, surge protection and overvoltage protection may fail, resulting in electric shock and fatal injury!**

## 2.6 Function Description

The inverter is equipped with the following functions:

### Conversion Function

The inverter converts the DC current into grid-compatible AC current and feeds the AC current into the grid.

### Data Storage

The inverter logs running information, error records, etc.

### Parameter Configuration

The inverter provides various settable parameters. Users can set parameters via the App to meet the requirements and optimize the performance.

### Communication Interface

The inverter is designed with standard RS485 communication interfaces and communication accessory port.

- The standard RS485 communication interfaces are used to establish communication with monitoring devices and to upload monitoring data to a monitoring background through communication cables.
- The communication accessory port is used to connect communication module manufactured by SUNGROW, and upload monitoring data through communication cables or wireless communication.

The inverter can be connected to communication devices via either of the two interfaces. When communication is established between the inverter and the communication devices, users can view inverter information or set inverter parameters, such as running parameter and protection parameter, through the iSolarCloud.



It is recommended to use the communication module from SUNGROW. Using a device from other companies may lead to communication failure or other unexpected damage.

### Protection Function

The protective functions are integrated in the inverter, including anti-island protection, DC reversed polarity protection, AC short circuit protection, leakage current protection, etc.

### Ripple Control

The inverter provides terminals (DRM) for connecting to a Ripple Control Receiver (RCR). After the connection, the grid dispatching center issues regulation instructions via dry contact (DI). The inverter can control power output according to the local preset instructions.


### PID recovery




The PID function may not be applicable in some areas. Please consult SUNGROW for details.

The PID effect (Potential Induced Degradation) of PV modules will cause serious damage to generated output and yield, which can be avoided or recovered by PID recovery function.

- For positive voltage scheme, after the PID is enabled, the voltage to ground of all PV strings is greater than 0, and therefore the PV string-to-ground voltage is a positive value.



- For negative voltage scheme, after the PID is enabled, the voltage to ground of all PV strings is lower than 0, and therefore the PV string-to-ground voltage is a negative value.



#### NOTICE

- Before enabling the PID recovery function, make sure the voltage polarity of the PV modules to ground meets requirement. If there are any questions, contact the PV module manufacturer or read the corresponding user manual.
- PID recovery function and reactive power generation at night cannot be enabled at the same time.
- If the voltage scheme for the PID protection/recovery function does not meet the requirement of corresponding PV modules, the PID will not work as expected or even damage the PV modules.
- If the PID recovery function is enabled, it only works at night.
- When the inverter is in the PID recovery state (the indicator blinks blue once at long intervals and blinks at short intervals for three times), disable the PID recovery in the iSolarCloud App before manually powering on and maintaining the inverter.

#### AFCI Function



The AFCI function may not be applicable in some areas. Please consult SUN-GROW for details.

- AFCI activation

This function can be enabled to detect whether arc occurs in the DC circuit of the inverter.

- AFCI self-test

This function is intended to detect whether the AFCI function of the inverter is normal.

- Clear AFCI Alarm

When the inverter detects the AFCI alarm, it stops working. Clear the AFCI alarm so that the inverter can restart the detection.

- AFPE

This device supports AFPE for arc detection and interruption.

- Coverage of AFCI protection

AFCI protection covers the PV modules up to the input terminals of the inverter.

- Implementation method of AFCI protection

This inverter is equipped with a fully-integrated AFPE, which is implemented within the inverter connected to the PV array and makes use of the enclosure and terminals of the inverter.

- Maximum number of strings per input or input port

1 string per input port.

- Reconnection methods

The following two reconnection methods are available for this device.

- 1 Manual reconnection

Reconnection can only be performed manually after arc interruption.

- 2 Remote manual reconnection

Reconnection can be performed via remote access to the AFPE after arc interruption.

## 3 Unpacking and Storage

### 3.1 Unpacking and Inspection

The product is thoroughly tested and strictly inspected before delivery. Nonetheless, damage may still occur during shipping. For this reason, please conduct a thorough inspection after receiving the product.

- Check the packing case for any visible damage.
- Check the scope of delivery for completeness according to the packing list.
- Check the inner contents for damage after unpacking.

Contact SUNGROW or the transport company in case of any damage or incompleteness, and provide photos to facilitate services.

Do not dispose of the original packing case. It is recommended to store the device in the original packing case when the product is decommissioned.

#### NOTICE

**After receiving the product, check whether the appearance and structural parts of the device are damaged, and check whether the packing list is consistent with the actual ordered product. If there are problems with the above inspection items, do not install the device and contact your distributor first. If the problem persists, contact SUNGROW in time.**

**If any tool is used for unpacking, be careful not to damage the product.**

### 3.2 Inverter Storage

Proper storage is required if the inverter is not installed immediately.

- Store the inverter in the original packing case with the desiccant inside.
- The storage temperature must be always between -40°C and +70°C, and the storage relative humidity must be always between 0 and 95 %, non-condensing.
- In case of stacking storage, the number of stacking layers should never exceed the limit marked on the outer side of the packing case.
- The packing case should be upright.
- If the inverter needs to be transported again, pack it strictly before loading and transporting it.

- Do not store the inverter in places susceptible to direct sunlight, rain, and strong electric field.
- Do not place the inverter in places with items that may affect or damage the inverter.
- Store the inverter in a clean and dry place to prevent dust and water vapor from eroding.
- Do not store the inverter in places with corrosive substances or susceptible to rodents and insects.
- Carry out periodic inspections. Inspection shall be conducted at least once every six months. If any insect or rodent bites are found, replace the packaging materials in time.
- If the inverter has been stored for more than a year, inspection and testing by professionals are required before it can be put into operation.

**NOTICE**

**Please store the inverter according to the storage requirements. Product damage caused by failure to meet the storage requirements is not covered by the warranty.**

## 4 Mechanical Mounting

### WARNING

Respect all local standards and requirements during mechanical installation.

### 4.1 Safety During Mounting

#### DANGER

Make sure there is no electrical connection before installation.  
Before drilling, avoid the water and electricity wiring in the wall.

#### WARNING

Poor installation environment will affect system performance!

- Install the inverter in a well-ventilated place.
- Ensure that the heat dissipation system or vent is not blocked.
- Do not install the inverter in an environment with flammable and explosive objects or smoke.

#### CAUTION

Improper handling may cause personal injury!

- When moving the inverter, be aware of its weight and keep the balance to prevent it from tilting or falling.
- Wear proper protective equipment before performing operations on the inverter.
- The bottom terminals and interfaces of the inverter cannot directly contact the ground or other supports. The inverter cannot be directly placed on the ground.

#### NOTICE

When installing devices, ensure that no device in the system causes it hard for the DC switch and the AC circuit breaker to act or hinders maintenance personnel from operating.

If drilling is required during installation:


- Wear goggles and protective gloves when drilling holes.
- Make sure to avoid the water and electricity wiring in the wall before drilling.
- Protect the product from shavings and dust.



## 4.2 Location Requirements


To a large extent, a proper installation location ensures safe operation, service life, and performance of the inverter.

- The inverter with protection rating IP66 can be installed both indoors and outdoors.
- The inverter should be installed at a height that allows easy viewing of the LED indicator panel, as well as easy electrical connection, operation and maintenance.



### 4.2.1 Environment Requirements

- The installation environment must be free of inflammable or explosive materials.
- The location should not be accessible to children.
- The ambient temperature and relative humidity must meet the following requirements.




- Please consult SUNGROW before installing inverters outdoors in areas prone to salt damage, which mainly are coastal areas within 500 meters of the coast. The deposition of salt fog varies largely with nearby seawater characteristics, sea wind, precipitation, relative humidity, terrain, and forest coverage.
- Install the inverter in a sheltered area to avoid direct sunlight and bad weather (e.g. snow, rain, lightning, etc.). The inverter will derate in high temperature environments for protection. If the inverter is installed in direct sunlight, it may cause power reduction as the temperature rises.
- The inverter is IP66 rated. In dusty environments such as places full of dust, smoke, or cotton fibers, particles may cling to the device's air outlet or heat sink, thus impacting its heat dissipation performance or even getting it damaged. Therefore, it is prohibited to install the inverter in dusty environments. If the inverter has to be installed in such environments, please clean its fans and heat sink on a regular basis to ensure a good heat dissipation performance.
- The inverter should be well ventilated. Ensure air circulation.

- It is strictly prohibited to install the inverter in environments with vibration and strong electromagnetic field. Strong-magnetic-field environments refer to places where magnetic field strength measures over 30A/m.
- The inverter generates noise during operation and is not recommended to be installed in living areas.

#### 4.2.2 Carrier Requirements

The mounting structure where the inverter is installed must comply with local/national standards and guidelines. Ensure that the installation surface is solid enough to bear four times the weight of the inverter and is suitable for the dimensions of the inverter (e.g. cement walls, plasterboard walls, etc.).


The structure should meet the following requirements:



#### 4.2.3 Angle Requirements


Install the inverter vertically or at the maximum allowable rear tilt angle. Do not install the inverter horizontally, forward, excessively backward, sideways, or upside down.

Inverters in floating plants cannot be installed at a back tilt.



### tilting backwards installation requirements

In case the installation site is a level surface, mount the inverter to the horizontal-mounting bracket to meet the mounting angle requirements, as shown in the figure below.




Take the following items into account when designing the bracket scheme:

- Consider onsite climate conditions and take anti-snow and anti-rain measures if necessary.
- Ensure that the waterproof connectors are at least 300mm higher than the ground surface.
- Bind the cables at the positions 300~350mm away from the DC connector, AC waterproof terminal, and communication waterproof terminal.
- The various waterproof terminals should be tightened with the torque specified in this manual to ensure that they are securely sealed.

#### 4.2.4 Clearance Requirements


Reserve enough clearance around the inverter to ensure sufficient space for heat dissipation.



\*When this distance is less than the distance shown, lift the inverter off the stand or wall before maintaining fans.

The distance from the bottom of the inverter to the ground is determined according to the bending radius of the selected AC cable and the installation environment, and the following requirements should be met :


- The distance from the bottom of the inverter to the ground should be  $\geq 650\text{mm}$ .
- The AC cable should be connected to the AC terminal vertically, and the length of the vertical cable should be  $\geq 200\text{mm}$ .



S317-I000

Contact the AC cable manufacturer for any questions.


In case of multiple inverters, reserve specific clearance between the inverters.



### Back-to-Back Installation


When installing inverters back-to-back, the distance between every two inverters should be at least 200 mm.

Add a baffle between the two inverters to form a heat dissipation channel. The baffle plate should be placed horizontally between two inverters and should not block the air outlet of inverters.




## 4.3 Installation Tools


Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.



Goggles



Earplugs




Dust mask



Safety gloves




Safety shoes




Utility knife




Anti-static wrist strap






Marker




Level

Hammer drill  
( $\phi 12$ )


Rubber mallet

Phillips screwdriver  
(M4, M5, M6)Open-end wrench  
(16 mm, 60 mm)Socket wrench set  
(M8)


Wire cutter




Wire stripper



Hydraulic plier



Heat gun

Crimping tool  
4–6mm<sup>2</sup>

Connector wrench

Multimeter  
 $\geq 1100$  Vdc


Vacuum cleaner

## 4.4 Moving the Inverter

Before installation, remove the inverter from the packing case and move it to the installation site. Follow the instructions below as you move the inverter:

- Always be aware of the weight of the inverter.
- Prevent the inverter from tilting or dropping.

Lift and move the inverter to the destination by using the side handles and bottom edge.



#### ⚠ CAUTION

**Improper handling may cause personal injury!**

- Arrange an appropriate number of personnel to carry the inverter according to its weight, and installation personnel should wear protective equipment such as anti-impact shoes and gloves.
- Attention must be paid to the center of gravity of the inverter to avoid tilting during handling.
- Placing the inverter directly on a hard ground may cause damage to its metal enclosure. Protective materials such as sponge pad or foam cushion should be placed underneath the inverter.
- Move the inverter by holding the handles on it. Do not move the inverter by holding the terminals.

## 4.5 Installing Mounting-bracket




figure 4-1 Dimensions of Mounting-bracket

### 4.5.1 Bracket-Mounted Installation


**Tool preparation**

| Name         | Specification        |
|--------------|----------------------|
| Marker       | —                    |
| Level        | -                    |
| Hammer drill | Bit: $\phi 12$       |
| Wrench       | Inner diameter: 16mm |


**Material preparation**

| Name            | Quantity | Specification | Source                             |
|-----------------|----------|---------------|------------------------------------|
| Bolt assembly   | 2        | M10           | Included in the delivery scope     |
| Steel u-channel | 2        | -             | Not included in the delivery scope |

**Step 1** Mark and drill holes in one steel u-channel according to the dimensions shown in the figure below. Two steel u-channels should be spaced 180 mm - 260 mm apart.



**Step 2** Secure the mounting-bracket to the steel u-channel with bolts.



-- End

#### 4.5.2 Wall-Mounted Installation

**Tool preparation**


| Name         | Specification        |
|--------------|----------------------|
| Maker        | —                    |
| Level        | -                    |
| Hammer drill | Bit: $\phi 12$       |
| Wrench       | Inner diameter: 16mm |

**Material preparation**

| Name           | Quantity | Specification | Source                             |
|----------------|----------|---------------|------------------------------------|
| Expansion bolt | 2        | M10           | Not included in the delivery scope |




**Step 1** Place the mounting-bracket at the installation place, adjust the angle with a level, and mark the location of the drilled holes.




S317-I013

**Step 2** Drill holes with a hammer drill. Clean up the holes, stuff the expansion bolts into the holes, and fix them with a rubber mallet. Use a wrench to tighten the nut to fix the end of the bolt, take off the nut, spring washer and flat washer for spare.



After removing the nut, spring washer, and flat washer, level the front of the expansion tube with the wall. Otherwise, the mounting brackets will not stay steady on the wall.

**Step 3** Secure the mounting-bracket with expansion bolts.



S317-I014

-- End

#### 4.5.3 Pole Installation

##### Tool preparation

| Name          | Specification        |
|---------------|----------------------|
| Marker        | —                    |
| Level         | -                    |
| Hammer drill* | Bit: $\phi 12$       |
| Wrench        | Inner diameter: 16mm |

\*Check if tools of other specifications are needed according to the bolts of the matching clamps.

### Material preparation


| Name            | Quantity | Specification                       | Source                             |
|-----------------|----------|-------------------------------------|------------------------------------|
| Bolt assembly   | 2        | M10                                 | Included in the delivery scope     |
| Bolt assembly   | 4        | M10                                 | Not included in the delivery scope |
| Steel u-channel | 2        | -                                   | Not included in the delivery scope |
| Clamp           | 2        | According to the pole specification | Not included in the delivery scope |

**Step 1** Erect and stabilize the pole at the installation site.




Please skip this step if the inverter is to be installed on a concrete pole, PV bracket, etc. through pole-mounting.


**Step 2** Mark and drill holes in steel u-channels according to the dimensions shown in the figure below. Two steel u-channels should be spaced 180 mm - 260 mm apart.



**Step 3** Secure the mounting-bracket to the steel u-channels with bolts.



**Step 4** Secure the steel u-channels to the pole with bolts and clamps.



-- End

## 4.6 Installing the Inverter

### Tool preparation


| Name                 | Specification |
|----------------------|---------------|
| Phillips screwdriver | M5            |


### Material preparation

| Name        | Quantity | Specification | Source                         |
|-------------|----------|---------------|--------------------------------|
| Cross screw | 2        | M5×16         | Included in the delivery scope |

**Step 1** Take out the inverter from the packing case.

**Step 2** Lift the inverter onto the mounting-bracket and make sure the mounting ears fit well into the grooves of the mounting-bracket.



**Step 3** Fix the inverter with screws.**-- End**

## 5 Electrical Connection

### 5.1 Safety Instructions

#### DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

- Operators must wear proper personal protective equipment during electrical connections.
- Must ensure that cables are voltage-free with a measuring instrument before touching DC cables.
- Respect all safety instructions listed in relevant documents about PV strings.

#### DANGER

- Before electrical connections, please make sure that the inverter switch and all switches connected to the inverter are set to "OFF", otherwise electric shock may occur!
- Ensure that the inverter is undamaged and all cables are voltage free before performing electrical work.
- Do not close the AC circuit breaker until the electrical connection is completed.

#### WARNING

Do not damage the ground conductor. Do not operate the product in the absence of a properly installed ground conductor. Otherwise, it may cause personal injury or product damage.

Please use measuring devices with an appropriate range. Overvoltage can damage the measuring device and cause personal injury.

Damage to the product caused by incorrect wiring is not covered by the warranty.

- Electrical connection must be performed by professionals.
- Operators must wear proper personal protective equipment during electrical connections.
- All cables used in the PV generation system must be firmly attached, properly insulated, and adequately dimensioned. Cables used shall comply with the requirements of local laws and regulations.
- The factors that affect cable selection include rated current, cable type, routing mode, ambient temperature, and maximum expected line loss.

**NOTICE**

**All electrical connections must comply with local and national/regional electrical standards.**

- **Cables used by the user shall comply with the requirements of local laws and regulations.**
- **Only with the permission of the national/regional grid department, the inverter can be connected to the grid.**

**NOTICE**

- **Install the external protective grounding cable first when performing electrical connection and remove the external protective grounding cable last when removing the inverter.**
- **Keep the AC output cable and the DC input cable close to each other during electrical connection.**
- **Comply with the safety instructions related to PV strings and the regulations related to the utility grid.**

**NOTICE**

- **After being crimped, the OT terminal must wrap the wires completely, and the wires must contact the OT terminal closely.**
- **When using a heat gun, protect the device from being scorched.**
- **Keep the PV+ cable and PV- cable close to each other when connecting DC input cables.**
- **Before connecting a power cable (such as the AC cable, the DC cable, etc.), confirm that the label and identifier on the power cable are correct.**
- **When laying out communication cables, separate them from power cables and keep them away from strong interference sources to prevent communication interruption.**
- **All vacant terminals must be covered with waterproof covers to prevent affecting the protection performance.**
- **Ensure that AC output cables are firmly connected. Failing to do so may cause inverter malfunction or damage to its AC connectors.**
- **When the wiring is completed, seal the gap at the cable inlet and outlet holes with fireproof/waterproof materials such as fireproof mud to prevent foreign matter or moisture from entering and affecting the long-term normal operation of the inverter.**



The cable colors in figures in this manual are for reference only. Please select cables according to local cable standards.

## 5.2 Terminal Description

All electrical terminals are located at the bottom of the inverter.




figure 5-1 Terminal Description

\* The image shown here is for reference only. The actual product received may differ.

| Item | Terminal                               | Mark                                                                                | Note                                                                                               |
|------|----------------------------------------|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| A    | DC Switch                              | DC SWITCH                                                                           | Used to switch on and off the DC input.                                                            |
| B    | Communication terminal                 | COM1                                                                                | For communication module connection.                                                               |
|      |                                        | COM2                                                                                | DI, DRM, DO, RS485, Smart Energy Meter                                                             |
| C    | PV terminals                           | PV1,PV2, PV3, PV4, PV5, PV6                                                         | 6 pairs of terminals ( SG25/30/33CX-P2)                                                            |
|      |                                        | PV1,PV2, PV3, PV4, PV5, PV6, PV7, PV8                                               | 8 pairs of terminals ( SG36/40/50CX-P2)                                                            |
| D    | AC wiring terminal                     | AC                                                                                  | Used for AC output cable connection.                                                               |
| E    | External protective grounding terminal |  | Used for reliable grounding of the inverter<br>2, use at least one of them to ground the inverter. |

table 5-1 The label of COM2 terminal

| DI   |      | DRM |      |      | DO  | RS485 |    | Meter |
|------|------|-----|------|------|-----|-------|----|-------|
| DI   | DI   | C   | D4/8 | D2/6 | COM | B1    | B1 | B2    |
| PGND | PGND | R   | D3/7 | D1/5 | NO  | A1    | A1 | A2    |


table 5-2 The label description of COM2 terminal

| No. | Label                         | Description                                                                                                                                                                                                     |
|-----|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | DI                            | emergency stop dry contact                                                                                                                                                                                      |
| 2   | DRM                           | <ul style="list-style-type: none"> <li>"AU"/"NZ": Demand response enabling device (DRED)</li> <li>"DE": Ripple Control Receiver (RCR)</li> </ul>                                                                |
| 3   | DO                            | fault output dry contact                                                                                                                                                                                        |
| 4   | RS485 (A1, B1) <sup>(1)</sup> | <ul style="list-style-type: none"> <li>Connect to the Logger, so as to implement data exchange with PC or other monitoring devices.</li> <li>Enable the communication between inverters in parallel.</li> </ul> |
| 5   | Meter (A2, B2) <sup>(1)</sup> | Connect to the Smart Energy Meter.                                                                                                                                                                              |

(1) When the inverter is connected to a third-party monitoring device, please confirm which communication interface is used, and whether it will cause loss of certain functions of the inverter.

### 5.3 Electrical Connection Overview

Connecting the inverter to the PV system requires connecting the inverter to the protective grounding point, to the grid, and to the PV strings.



( A ) PV string

( B ) Inverter

( C ) Grid

( D ) Monitoring device

( E ) AC circuit breaker



table 5-3 Cable Requirements

| No. | Cable                       | Type                                                           | Specification               |                                                               |
|-----|-----------------------------|----------------------------------------------------------------|-----------------------------|---------------------------------------------------------------|
|     |                             |                                                                | Cable Di-<br>ameter<br>(mm) | Cross-sectional Area(mm <sup>2</sup> )                        |
| 1   | DC cable                    | Multi-core PV cable with a maximum with-stand voltage of 1100V | 4.7 ~ 6.4                   | 4 ~ 6                                                         |
| 2   | External grounding cable    | Outdoor single-core copper wire                                | /                           | The same as that of the PE wire in the AC cable               |
| 3   | AC cable                    | Outdoor four-core/five-core copper wire                        | 18 ~ 38                     | L1,L2,L3,N wire : 16~35(SG25/30/33/36/40CX-P2)                |
|     |                             |                                                                |                             | PE wire : 16**(SG25/30/33/36/40CX-P2)                         |
|     |                             | Outdoor four-core/five-core aluminum wire*                     |                             | L1,L2,L3,N wire : 35~50(SG50CX-P2)                            |
|     |                             |                                                                |                             | PE wire : refer to"table 5-4 PE wire requirements"(SG50CX-P2) |
| 3   | AC cable                    | Outdoor four-core/five-core copper wire                        | 18 ~ 38                     | L1,L2,L3,N wire : 25~35(SG25/30/33/36/40CX-P2)                |
|     |                             |                                                                |                             | PE wire : 16**(SG25/30/33/36/40CX-P2)                         |
|     |                             | Outdoor four-core/five-core aluminum wire*                     |                             | L1,L2,L3,N wire : 35~50(SG50CX-P2)                            |
|     |                             |                                                                |                             | PE wire : refer to"table 5-4 PE wire requirements"(SG50CX-P2) |
| 4   | Communi-<br>cation<br>cable | Shielded twisted pair                                          | 5.3 ~ 7                     | 0.5~1                                                         |
|     |                             | CAT 5E outdoor shielded network cable                          |                             | /                                                             |

\*A copper to aluminum adapter terminal is required when an aluminum cable is used. For details, refer to "[Aluminum Cable Requirements](#)".

\*\* The specifications are valid only when the phase wire and PE wire use the same material. If otherwise, ensure that the cross section of the PE wire produces a conductance equivalent to that of the 16mm<sup>2</sup> in the table.


table 5-4 PE wire requirements

| PE wire cross section                  | Note                                                                                                                                                                                                                              |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S/2<br>(S: Phase wire cross-section S) | The specifications are valid only when the phase wire and PE wire use the same material. If otherwise, ensure that the cross section of the PE wire produces a conductance equivalent to that of the wire specified in the table. |

Other sizes of grounding cables that meet local standards and safety regulations can also be used for grounding connections. But SUNGROW shall not be held liable for any damage caused.

## 5.4 Crimp OT/DT terminal

### Crimp OT/DT terminal



1. Heat shrink tubing


2. OT/DT terminal

3. Hydraulic pliers

4. Heat gun

### Aluminum Cable Requirements

If an Aluminum cable is selected, use a copper to Aluminum adapter terminal to avoid direct contact between the copper bar and the Aluminum cable.



**figure 5-2** Aluminum Cable Connection

1. Copper to Aluminum adapter terminal

2. Flange nut

3. Aluminum cable

#### NOTICE

Ensure that the selected terminal can directly contact with the copper bar. If there are any problems, contact the terminal manufacturer.

Ensure that the copper bar is not in direct contact with the aluminum wire. Otherwise, electrochemical corrosion may occur, impairing the reliability of electrical connection.

## 5.5 External Protective Grounding Connection

#### **⚠ DANGER**

##### Electric shock!

- Make sure that the grounding cable is connected reliably. Otherwise, it may cause electric shock.

#### **⚠ WARNING**

- Since the inverter is not equipped with a transformer, neither the negative electrode nor the positive electrode of the PV string can be grounded. Otherwise, the inverter will not operate normally.
- Connect the grounding terminal to the external protective grounding point before AC cable connection, PV string connection, and communication cable connection.
- The external protective grounding point provides a reliable ground connection. Do not use an improper grounding conductor for grounding. Otherwise, it may cause product damage or personal injury.
- Depending on Local Rules, please also ground the PV panel subconstruction to the same common grounding point (PE Bar) in addition to local lightning protection rules.

**⚠ WARNING**

The external protective grounding terminal must meet at least one of the following requirements.

- The cross-sectional area of the grounding cable is not less than 10 mm<sup>2</sup> for copper wire or 16 mm<sup>2</sup> for aluminum wire. It is recommended that both the external protective grounding terminal and the AC side grounding terminal be reliably grounded.
- If the cross-sectional area of the grounding cable is less than 10 mm<sup>2</sup> for copper wire or 16 mm<sup>2</sup> for aluminum wire, ensure that both the external protective grounding terminal and the AC side grounding terminal are reliably grounded.

The grounding connection can be made by other means if they are in accordance with the local standards and regulations, and SUNGROW shall not be held liable for the possible consequences.

### 5.5.1 External Protective Grounding Requirements

All non-current carrying metal parts and device enclosures in the PV power system should be grounded, for example, brackets of PV modules and inverter enclosure.


When there is only one inverter in the PV system, connect the external protective grounding cable to a nearby grounding point.

When there are multiple inverters in the PV system, connect the external protective grounding terminals of all inverters and the grounding points of the PV module brackets to ensure equipotential connections to ground cables (according to the onsite conditions).

### 5.5.2 Connection Procedure

**Step 1** Prepare the cable and OT/DT terminal, refer to "[Crimp OT/DT terminal](#)".

**Step 2** Remove the screw on the grounding terminal and fasten the cable with a screwdriver.



S317-E019

**Step 3** Apply paint to the grounding terminal to ensure corrosion resistance.



The grounding screws have been anchored to the side of the inverter before delivery, and do not need to be prepared.

There are two grounding terminals. Use one of them to ground the inverter.

-- End

## 5.6 AC Cable Connection

### 5.6.1 AC Side Requirements



Only with the permission of the local grid department, the inverter can be connected to the grid.

Before connecting the inverter to the grid, ensure the grid voltage and frequency comply with requirements, for which, refer to "**Technical Data**". Otherwise, contact the electric power company for help.

#### AC Circuit Breaker

An independent circuit breaker or fuse should be installed on the output side of the inverter to ensure safe disconnection from the grid.

| Inverter  | Recommended Rated Voltage | Recommended Rated Current |
|-----------|---------------------------|---------------------------|
| SG25CX-P2 | 400V                      | 63 A                      |
| SG30CX-P2 | 400V                      | 63 A                      |
| SG33CX-P2 | 400V                      | 80 A                      |
| SG36CX-P2 | 400V                      | 80 A                      |
| SG40CX-P2 | 400V                      | 100 A                     |
| SG50CX-P2 | 400V                      | 125 A                     |

#### WARNING

**AC circuit breakers should be installed on the output side of the inverter and the grid side to ensure safe disconnection from the grid.**

- Determine whether an AC circuit breaker with greater overcurrent capacity is required based on actual conditions.
- Do not connect any local load between the inverter and the AC circuit breaker.
- Multiple inverters cannot share one AC circuit breaker.

### Residual Current Monitoring Device

With an integrated universal current-sensitive residual current monitoring unit included, the inverter will disconnect immediately from the mains power once a fault current with a value exceeding the limit is detected.

However if an external residual current device (RCD) (type A is recommended) is mandatory, the switch must be triggered at the residual current. RCD of other specifications can also be used according to local standard. The recommended residual current is as follows.

| Inverter  | Recommended Residual Current |
|-----------|------------------------------|
| SG25CX-P2 | 300 mA                       |
| SG30CX-P2 | 300 mA                       |
| SG33CX-P2 | 330 mA                       |
| SG36CX-P2 | 360 mA                       |
| SG40CX-P2 | 400 mA                       |
| SG50CX-P2 | 500 mA                       |

### Multiple Inverters in Parallel Connection


If multiple inverters are connected in parallel to the grid, ensure that the total number of parallel inverters does not exceed 30.

## 5.6.2 Requirements for OT/DT Terminal

OT / DT terminals (not included in the delivery scope) are required for fixing AC cables to the terminal block. Purchase the OT / DT terminals according to the following requirements.

### OT / DT Terminals of Phase Wire

- Specification: M8



**figure 5-3** Specifications of the Crimped OT/DT Terminal


### OT / DT Terminal of PE Wire

- Specification: M8

## 5.6.3 Connection Procedure


**Step 1** Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.

**Step 2** Take out the AC junction box and loosen the swivel nut. Remove the seals and select an appropriate one according to cable outer diameter. Lead the cable through the swivel nut, seal, and junction box successively.




| Outer diameter D(mm) | Seals |
|----------------------|-------|
| 18 ~ 24              | a+b+c |
| 24 ~ 30              | a+b   |
| 30 ~ 38              | a     |

**Step 3** Make the cable and crimp OT/DT terminal.




**Step 4** Remove the AC protective cap.




**Step 5** Secure the wires to corresponding terminals. Gently pull the cable backwards to ensure firm connection.

**NOTICE**


**Observe the terminal layout on the block. Do not connect the phase wires to "PE" terminal or "N" terminal. Otherwise, unrecoverable damage to the inverter may follow.**




Ensure that the depth L of the socket used is not less than 18mm.






**Step 6** Secure the junction box.**NOTICE**

Ensure that the junction box is properly assembled. Failure to do so may affect the waterproof performance of the AC side, and the loss caused by this is not covered by the warranty.



**Step 7** Gently pull the cable backwards to ensure firm connection, and fasten the swivel nut clockwise.



-- End

## 5.7 DC Cable Connection

### **⚠ DANGER**

The PV string will generate lethal high voltage when exposed to sunlight.

- Respect all safety instructions listed in relevant documents about PV strings.

**⚠ WARNING**

- **Make sure the PV array is well insulated to ground before connecting it to the inverter.**
- **Make sure the maximum DC voltage and the maximum short circuit current of any string never exceed inverter permitted values specified in "Technical Data".**
- **Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness.**
- **During the installation and operation of the inverter, please ensure that the positive or negative electrodes of PV strings do not short-circuit to the ground. Otherwise, an AC or DC short-circuit may occur, resulting in equipment damage. The damage caused by this is not covered by the warranty.**
- **Electric arc or contactor over-temperature may occur if the DC connectors are not firmly in place, and the loss caused is not covered by the warranty.**
- **If the DC input cables are reversely connected or the positive and negative terminals of different MPPT are shorted to ground at the same time, while the DC switch is in the "ON" position, do not operate immediately. Otherwise, the inverter may be damaged. Please turn the DC switch to "OFF" and remove the DC connector to adjust the polarity of the strings when the string current is lower than 0.5 A.**
- **Use the DC connectors supplied with the product for DC cable connection. Using incompatible DC connectors may result in serious consequences, and the device damage is not covered under warranty.**
- **Inverters do not support full parallel connection of strings (Full parallel connection refers to a connection method in that strings are connected in parallel and then connected to the inverter separately).**
- **Do not connect one PV string to multiple inverters. Otherwise, the inverters may be damaged.**

**NOTICE**

The following requirements about PV string connection must be met. Otherwise, it may cause irreversible damage to the inverter, which is not covered by the warranty.

- **Mixed use of PV modules of different brands or models in one MPPT circuit, or PV modules of different orientation or inclination in a string may not damage inverter, but will cause system bad performance!**
- **The inverter enters standby state when the input voltage ranges between 1,000 V and 1,100 V. The inverter returns to running state once the voltage returns to the MPPT operating voltage range, namely, 160 V to 1,000 V.**


**NOTICE**

**Note the following items when laying out cables on site:**

- The axial tension on PV connectors must not exceed 80 N. Avoid axial cable stress on the connector for a long time during field wiring.
- Radial stress or torque must not be generated on PV connectors. It may cause the connector waterproof failure and reduce connector reliability.
- Leave at least 50 mm of slack to avoid the external force generated by the cable bending affecting the waterproof performance.
- Refer to the specifications provided by the cable manufacturer for the minimum cable bending radius. If the required bending radius is less than 50 mm, reserve a bending radius of 50 mm. If the required bending radius is greater than 50 mm, reserve the required minimum bending radius during wiring.

### 5.7.1 PV Input Configuration

- As shown in the figure below, the inverter is provided with multiple PV inputs, and each PV input is designed with an MPP tracker.
- Each PV input operates independently and has its own MPPT. In this way, string structures of each PV input may differ from each other, including PV module type, number of PV modules in each string, angle of tilt, and installation orientation.
- A maximum of two PV strings can be connected to an MPPT controller. For the best use of PV power, the type, quantity, tilt, and orientation of PV modules connected to the same MPPT shall be the same.



**figure 5-4** PV Input Configuration

Prior to connecting the inverter to PV inputs, the specifications in the following table should be met:

| Open-circuit Voltage Limit | Max. Current for Input Connector |
|----------------------------|----------------------------------|
| 1100 V                     | 20 A                             |
|                            | 30 A ( For India )               |

### 5.7.2 Assembling PV Connectors

#### **⚠ DANGER**


**High voltage may be present in the inverter!**

- **Ensure all cables are voltage-free before performing electrical operations.**
- **Do not connect the AC circuit breaker before finishing electrical connection.**




SUNGROW provides corresponding PV connectors in the scope of delivery for quick connection of PV inputs. To ensure IP66 protection, use only the supplied connector or the connector with the same ingress of protection.

**Step 1** Strip the insulation from each DC cable by 8 mm ~ 10 mm.




**Step 2** Assemble the cable ends with the crimping pliers.




1: Positive crimp contact

2 : Negative crimp contact

**Step 3** Lead the cable through the cable gland, and insert the crimp contact into the insulator until it snaps into place. Gently pull the cable backward to ensure firm connection.



**Step 4** Tighten the cable gland and the insulator.



**Step 5** Check for polarity correctness.


**NOTICE**

If the PV polarity is reversed, the inverter will be in a fault or alarm state and will not operate normally.


-- End

### 5.7.3 Installing PV Connector

**Step 1** Ensure that the DC switch is in "OFF" position. Otherwise, manually turn it to "OFF".




**Step 2** Check the cable connection of the PV string for polarity correctness and ensure that the open circuit voltage in any case does not exceed the inverter input limit of 1,100 V.



#### NOTICE

The multimeter must have a DC voltage range of at least 1100 V. If the voltage is a negative value, the DC input polarity is incorrect. Please correct the DC input polarity. If the voltage is greater than 1100 V, too many PV modules are configured to the same string. Please remove some PV modules.

**Step 3** Connect the PV connectors to corresponding terminals until there is an audible click.



**Step 4** Follow the foregoing steps to connect PV connectors of other PV strings

**Step 5** Seal any unused PV terminal with a terminal cap.

#### NOTICE


Turn the corresponding DC switch to "ON" after the PV string is connected to the PV terminal on the inverter.

-- End

## 5.8 Communication Connection

### 5.8.1 Wireless Communication Module Connection (optional)

Install the wireless communication module to the communication interface with a silk screen of COM1 at the bottom of the inverter.



\*The image shown here is for reference only. The actual product you receive may differ.

#### NOTICE

**Once the communication module is in use, do not connect the inverter to a data logger at the same time via RS485. Please contact SUNGROW for any further queries.**



For details on module installation and configuration, refer to the manual delivered together with the module.

### 5.8.2 WiNet-S Connection (optional)

The WiNet-S module supports Ethernet communication and WLAN communication. It is not recommended to use both communication methods at the same time.


For details, see the quick guide for the WiNet-S module. Scan the following QR code for the quick guide.






### 5.8.2.1 Ethernet Communication

**Step 1 (Optional)** Strip the insulation layer of the communication cable with an Ethernet wire stripper, and lead the corresponding signal cables out. Insert the stripped communication cable into the RJ45 plug in the correct order, and crimp it with a crimper.




Skip this step if a standard network cable with RJ45 plug is prepared.


**Step 2** Unscrew the swivel nut from the communication module and take out the inner sealing ring.




**Step 3** Unscrew the housing from the communication module.




**Step 4** Thread the network cable through the swivel nut and gasket. Afterwards, route the cable into the opening of the sealing. Finally, insert the cable through the housing.



**Step 5** Insert the RJ45 plug into the front plug connector until there is an audible click and tighten the housing. Install the gasket and fasten the swivel nut.



**Step 6** Remove the waterproof lid from the **COM1** terminal and install WiNet-S.




**Step 7** Slightly shake it by hand to determine whether it is installed firmly.

-- End

#### 5.8.2.2 WLAN Communication

**Step 1** Remove the waterproof lid from the **COM1** terminal.

**Step 2** Install the module. Slightly shake it by hand to determine whether it is installed firmly, as shown below.




**Step 3** Refer to the guide delivered with the module for the set-up.


-- End

### 5.8.3 RS485 Connection

Where there is only one inverter, the RS485 can be connected to an external device for the communication, as shown in the following figure.



In case of multiple inverters, all the inverters can be connected via RS485 cables in the daisy chain manner, as shown in the following figure.




### 5.8.3.1 Assembling the COM Connector




SUNGROW cooperates with multiple suppliers on communication connectors, so there may be cases where two types of communication connectors are received. Both communication connectors are wired in the same way, and the actual product received shall prevail.


**Step 1** Unscrew the swivel nut from the connector.




**Step 2** Take out the terminal block.




**Step 3** Remove the seal and lead the cable through the cable gland.



**Step 4** Remove the cable jacket and strip the wire insulation.




**Step 5** Plug the wires into the **RS485** terminal according the labels on the bottom of the inverter.




**Step 6** Pull the wires outward to check whether they are firmly installed.

**Step 7** Insert the terminal block into the connector until it snaps into place with an audible click.




**Step 8** Fasten the swivel nut.




-- End

### 5.8.3.2 Installing the COM Connector

**Step 1** Remove the waterproof lid from the **COM** terminal.



**Step 2** Insert the COM connector into **COM** terminal on the bottom of the inverter until there is an audible click.



-- End

#### 5.8.4 Smart Energy Meter Connection

The inverter can provide export control but will require the use of a external smart meter. The export control functionality has not been tested to AS/NZS 4777.2:2020.

The inverter is equipped with the feed-in power limit function, so as to meet the requirements of some national standards or grid standards for the output power at the grid connection point. For the setting of feed-in power limit, refer to the section "[7.3.2 Login Procedure](#)"

Contact SUNGROW to ensure that the Smart Energy Meter model is available locally.



This section mainly describes the cable connections on the inverter side. Refer to the quick guide delivered with the Smart Energy Meter for the connections on the meter side.

##### Procedure

For detailed connection description of the Smart Energy Meter cable, refer to the section "[5.8.3 RS485 Connection](#)". Plug the wires into the **Meter** terminal according the labels on the bottom of the inverter.

##### NOTICE

**The energy meter is mainly used to detect the direction and magnitude of the current. And the energy meter data may not be used for billing purposes.**

### 5.8.5 Dry Contact Connection

#### NOTICE

**Dry contact cables require a cross section of 1 mm<sup>2</sup> to 1.5 mm<sup>2</sup>.**

**The connection procedure of the dry contact is the same as that of the RS485 terminal block.**

#### 5.8.5.1 Dry Contact Function

Connection method of the dry contacts is similar to that of the RS485 terminal block.

**DI terminal (emergency stop dry contact):** the dry contact can be configured to be an emergency stop contact.

When the DI contact and PGND contact are shorted by external controlled switch (The external switch can be configured as normally open contact or normally closed contact), the inverter will immediately stop.

**NS terminal:** NS Protection is used for German market currently. For plant sized more than 30kVA, inverter NS Protection terminals could be used in daisy chain to external NS Protection Relay to realize emergency stop when NS Protection Relay change its dry contact status due to the grid abnormal running status.

NS Protection(including Passive Valid) can be set. When NS Protection is enabled on the iSolarCloud, the inverters will operate normally when DI contact and PGND contact are shorted by external controlled switch, and the inverters will emergently stop when DI contact and PGND contact are disconnected.



The dry contacts only support passive switch signal input.

When wiring DI dry contacts, ensure that the maximum wiring distance meet the requirements in "[10.2 Wring Distance of DI Dry Contact](#)".

**DO terminal (fault output dry contact):** The relay can be set to output fault alarms, and user can configure it to be a normally open contact (COM & NO).

Use LED indicators or other equipment to indicate whether the inverter is in the faulty state.

Devices connected to the relay should comply with related requirements:

| AC-Side Requirements  | DC-Side Requirements |
|-----------------------|----------------------|
| Max. voltage: 250 Vac | Max. voltage: 30Vdc  |
| Max. current: 5A      | Max. current: 5A     |

#### 5.8.5.2 Wiring Procedure

For detailed connection description of the DI/DO cable, refer to the section "[5.8.3 RS485 Connection](#)". Plug the wires into the **DI/DO** terminal according the labels on the bottom of the inverter.

### 5.8.6 DRM Connection

DRM and Ripple Control support only one function at the same time.

#### DRM

In Australia and New Zealand, the inverter supports the demand response modes as specified in the standard AS/NZS 4777.

The following figure shows the wiring between the inverter and the external DRED.




table 5-5 Method of Asserting DRM

| Mode | Asserted by Shorting Terminals on Inverter | Switch Operation on External DRED |
|------|--------------------------------------------|-----------------------------------|
| DRM0 | R & C                                      | Close S1 and S5                   |



Enable the DRM function through the iSolarCloud APP. If there are any problems, contact your distributor first. If the problem persists, contact SUNGROW.

The DRM function is only applicable to devices for Australia and New Zealand.

#### Ripple Control

In Germany, the grid company uses the Ripple Control Receiver to convert the grid dispatching signal and send it as a dry contact signal.

Wiring of the ripple control receiver dry contact cables is shown in the figure below:






table 5-6 Method of Asserting DI Mode


| S1 | S2 | S3 | S4 | Switch Operation on External RCR | Output power (in % of the Max. AC output power) |
|----|----|----|----|----------------------------------|-------------------------------------------------|
| 0  | 0  | 0  | 0  | None                             | 100%                                            |
| 1  | 0  | 0  | 0  | Close S1                         | 100%                                            |
| 0  | 1  | 0  | 0  | Close S2                         | 60%                                             |
| 0  | 0  | 1  | 0  | Close S3                         | 30%                                             |
| 1  | 1  | 0  | 0  | Close S1 and S2                  | 0% (disconnect from grid)                       |

### 5.8.6.1 Assembling the COM Connector




SUNGROW cooperates with multiple suppliers on communication connectors, so there may be cases where two types of communication connectors are received. Both communication connectors are wired in the same way, and the actual product received shall prevail.


**Step 1** Unscrew the swivel nut from the connector.




**Step 2** Take out the terminal block.




**Step 3** Remove the seal and lead the cable through the cable gland.



**Step 4** Remove the cable jacket by 7 mm–10 mm.




**Step 5** Plug the wires into the corresponding terminal according the labels on the bottom of the inverter.




**Step 6** Pull the wires outward to check whether they are firmly installed.

**Step 7** Insert the terminal block into the connector until it snaps into place with an audible click.




**Step 8** Fasten the swivel nut.




**-- End**

#### 5.8.6.2 Installing the COM Connector

**Step 1** Remove the waterproof lid from the **COM** terminal.



**Step 2** Insert the COM connector into **COM** terminal on the bottom of the inverter until there is an audible click.



**Step 3** Pull cables outwards to confirm whether they are fastened firmly.

**Step 4** Connect the other end to the DRED / Ripple Control Receiver device.

**-- End**

## 6 Commissioning

### 6.1 Inspection Before Commissioning

Check the following items before starting the inverter:

- All equipment has been reliably installed.
- DC switch(es) and AC circuit breaker are in the "OFF" position.
- The ground cable is properly and reliably connected.
- The AC cable is properly and reliably connected.
- The DC cable is properly and reliably connected.
- The communication cable is properly and reliably connected.
- The vacant terminals are sealed.
- No foreign items, such as tools, are left on the top of the machine or in the junction box (if there is).
- The AC circuit breaker is selected in accordance with the requirements of this manual and local standards.
- All warning signs & labels are intact and legible.

### 6.2 Commissioning Procedure

If all of the items mentioned above meet the requirements, proceed as follows to start up the inverter for the first time.

**Step 1** Rotate the DC switch of the inverter to the "ON" position, the indicator blinks blue slowly.

#### NOTICE

- **Strictly follow the preceding sequence. Otherwise, the product may be damaged, and the loss caused is not covered by the warranty.**
- **If the DC side is powered up while the AC side is not, the inverter indicator may turn red, and the inverter will report a fault named "Grid Power Outage" (the fault information can be viewed on the iSolarCloud App, see "Records" for details). The fault is automatically cleared when the AC circuit breaker between the inverter and the grid is closed.**
- **Before closing the AC circuit breaker between the inverter and the power grid, use a multimeter that is set to the AC gear to ensure that the AC voltage is within the specified range. Otherwise, the inverter may be damaged.**

**Step 2** Close the AC circuit breaker between the inverter and the grid.

**Step 3** Install the iSolarCloud App, see ["7.2 Installing App"](#) for details.

**Step 4** Set initial protection parameters via the iSolarCloud App when the inverter is connected to the grid for the first time (see Step 4 in ["7.3.2 Login Procedure"](#) for details). If the irradiation and grid conditions meet requirements, the inverter normally operates.

**Step 5** The home page is automatically displayed when the setting is completed. The indicator is steady blue, and the inverter is in grid-connected operation.

**-- End**

## 7 iSolarCloud App

### 7.1 Brief Introduction

The iSolarCloud App can establish communication connection to the inverter via the Bluetooth, thereby achieving near-end maintenance on the inverter. Users can use the App to view basic information, alarms, and events, set parameters, or download logs, etc.



Screenshots in this manual are based on the Android system V2.1.6 , and the actual interfaces may differ.

### 7.2 Installing App

#### Method 1

Download and install the App through the following application stores:

- MyApp (Android, mainland China users)
- Google Play (Android, users other than mainland China ones)
- App Store (iOS)

#### Method 2

Scan the following QR code to download and install the App according to the prompt information.



The App icon appears on the home screen after installation.



## 7.3 Login

### 7.3.1 Requirements

The following requirements should be met:

- The AC or DC side of the inverter is powered-on.
- The mobile phone is within 5 meters away from the inverter and there are no obstructions in between.
- The Bluetooth function of the mobile phone is enabled.




The inverter can only pair with one phone at a time through Bluetooth.

### 7.3.2 Login Procedure

**Step 1** Open the App to enter the login page, tap **Local Access** at the bottom of the page to go to the next page.

**Step 2** Establish the Bluetooth connection by either of the two following ways. If the LED indicator flashes blue, the connection is successfully established.

- Scan the QR code on the side of the inverter for Bluetooth connection.
- Tap "Manual connection" and select "Others" at the bottom of the page, the Bluetooth search page will automatically pop up, and select the inverter to be connected according to the SN on the nameplate on the side of the inverter body.



**figure 7-1** Bluetooth Connection

**Step 3** Enter the identity verification interface after the Bluetooth connection is established.






figure 7-2 Login



The Account is "user", and the initial password is "pw1111" or "111111" which should be changed for the consideration of account security.

To set inverter parameters related to grid protection and grid support, contact your distributor to obtain the advanced account and corresponding password. If the distributor is unable to provide the required information, contact SUNGROW.

**Step 4** If the inverter is not initialized, you will enter the quick setting interface of initializing protection parameters.




figure 7-3 Initialization Protection Parameter

#### NOTICE

The Country/Region must be set to the country where the inverter is installed. Otherwise, the inverter may report errors.

**Step 5** When the country is set to Australia, additionally set the applicable network service provider and then the grid type. Tap **Power Company** to select the correct power company.




figure 7-4 Initialization Power Company

The image shown here is for reference only. Refer to the actual interface for the supported network service providers.

table 7-1 Power Company Information

| Network Service Provider       | Grid Type                                                                                                                                                           |
|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AS/NZS 4777.2:2015             | /                                                                                                                                                                   |
| AS/NZS 4777.2:2020 Australia A | /                                                                                                                                                                   |
| AS/NZS 4777.2:2020 Australia B | /                                                                                                                                                                   |
| AS/NZS 4777.2:2020 Australia C | /                                                                                                                                                                   |
| ENERGEX & Ergon Energy         | <ul style="list-style-type: none"> <li>STNW1170: single phase &lt; 10 kVA &amp; three phase &lt; 30 kVA</li> <li>STNW1174 :30 kVA &lt; PN ≤ 1500 kVA</li> </ul>     |
| Endeavour Energy               | MDI 0043                                                                                                                                                            |
| Ausgrid                        | NS194                                                                                                                                                               |
| Jemena                         | <ul style="list-style-type: none"> <li>≤ 10kVA per phase (or 30 kVA per three phase)</li> <li>ELE GU 0014: 30-200kVA</li> </ul>                                     |
| CitiPower & Powercor           | <ul style="list-style-type: none"> <li>≤ 5 kVA for single-phase &amp; 30 kVA for three-phase</li> <li>&gt; 30 kVA three-phase</li> </ul>                            |
| United Energy                  | <ul style="list-style-type: none"> <li>UE-ST-2008.1: ≤ 10 kW for single-phase &amp; 30 kW for three-phase</li> <li>UE-ST-2008.2: &gt; 30 kVA three-phase</li> </ul> |
| PowerWater                     | Embedded Generation Notice Photovoltaic Systems:2020                                                                                                                |

| Network Service Provider | Grid Type                                                                                                                                                                                             |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SA Power Networks        | <ul style="list-style-type: none"> <li>TS129-2019: &lt; 10 kW for single-phase &amp; 30 kW for three-phase</li> <li>TS130-2017: &gt; 30 kW &amp; ≤ 200 kW</li> <li>TS131-2018: &gt; 200 kW</li> </ul> |
| Horizon Power            | <ul style="list-style-type: none"> <li>HPC-9DJ-13-0001-2019: ≤ 10 kVA for single-phase &amp; 30 kVA for three-phase</li> <li>HPC-9DJ-13-0002-2019: &gt; 30 kVA &amp; ≤ 1 MVA</li> </ul>               |
| westernpower             | EDM # 33612889-2019                                                                                                                                                                                   |
| AusNet Services          | Basic Micro Embedded Generation:2020                                                                                                                                                                  |

For compliance with AS/NZS 4777.2:2020, please select from Australia A/B/C. Please contact your electricity grid operator for which region to use.

**Step 6** The function of the feed-in limitation is to control the amount of power injected in the grid by the plant. In some situations, this function is also called as **Export limitation** or **Zero export**. The feed-in limitation function requires the using of Smart Energy Meter. Without the Smart Energy Meter, the feed-in limitation function will be unavailable.

FEED-IN LIMITATION

Feed-in Limitation

Feed-in Limitation Value

0.00 kW

Feed-in Limitation Ratio

0.0 %

table 7-2 Description of feed-in limitation parameters

| Parameter                       | Default value | Range                          |
|---------------------------------|---------------|--------------------------------|
| <b>Feed-in Limitation</b>       | Off           | On / Off                       |
| <b>Feed-in Limitation Value</b> | 0.00kW        | 0 ~ Max. AC output power       |
| <b>Feed-in Limitation Ratio</b> | 0.0%          | 0 ~ 100%×Active Overload Rate* |

\*The active overload rate of SG30CX-P2 in Germany, Belgium, Austria, Ukraine, and Denmark is 1, and in other regions is 1.1 (depending on local grid regulations). The active overload rate of SG25/33/36/40/50CX-P2 is 1.1.


**Step 7** After finishing the settings, tap **TUNR ON DEVICE** at the upper right corner and the device will be initialized. The App will send start instructions and the device will start and operate.

**Step 8** If the inverter is initialized, the App automatically turns to its home page.

-- End

## 7.4 Function Overview

The App provides parameter viewing and setting functions, as shown in the following figure.



**figure 7-5** App Function Tree Map

## 7.5 Home

After login, the home page is as follows:




figure 7-6 Home Page

table 7-3 Home Page Description

| No. | Designation        | Description                                                                                                                                                                                |
|-----|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Date and time      | System date and time of the inverter                                                                                                                                                       |
| 2   | Inverter state     | Present operation state of the inverter. For details, refer to <a href="#">"table 7-4 Description of Inverter State"</a> .                                                                 |
| 3   | PID function state | Present state of the PID function. For details, refer to <a href="#">"table 7-5 Description of PID State"</a>                                                                              |
| 4   | Power flow chart   | Display the PV power generation power, feed-in power, etc. The line with an arrow indicates energy flow between connected devices, and the arrow pointing indicates energy flow direction. |
| 5   | Power generation   | Today power yield and accumulative power yield of the inverter                                                                                                                             |
| 6   | Real-time power    | Output power of the inverter                                                                                                                                                               |
| 7   | Power curve        | Curve showing change of power between 5 am and 23 pm every day<br>(Each point on the curve represents the percentage of present inverter power to rated power)                             |
| 8   | Navigation bar     | Including "Home", "Run Information", "Records", and "More"                                                                                                                                 |

table 7-4 Description of Inverter State

| State              | Description                                                                                                                                                                                                                       |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Run                | After being energized, inverter tracks the PV arrays' maximum power point (MPP) and converts the DC power into AC power. This is the normal operation mode.                                                                       |
| Stop               | Inverter is stopped.                                                                                                                                                                                                              |
| Press to Shut Down | Inverter will stop operation by tapping "Stop" via app. In this way, inverter internal DSP stops. Restart the inverter via app if needed.                                                                                         |
| Standby            | Inverter enters standby mode when DC side input is insufficient. In this mode inverter will wait within the standby duration.                                                                                                     |
| Initial standby    | The inverter is in the initial power-on standby state.                                                                                                                                                                            |
| Starting up        | The inverter is initializing and synchronizing with the grid.                                                                                                                                                                     |
| Warn run           | Warning information is detected.                                                                                                                                                                                                  |
| Derating           | The inverter derates actively due to environmental factors such as temperature or altitude                                                                                                                                        |
| Dispatch Running   | The inverter runs according to the scheduling instructions received from the monitoring background                                                                                                                                |
| Shut down          | If a fault occurs, inverter will automatically stop operation, and the AC relay acts. The fault information will be displayed on the app. Once the fault is removed in recovery time, inverter will automatically resume running. |

table 7-5 Description of PID State

| State                | Description                                                                                                          |
|----------------------|----------------------------------------------------------------------------------------------------------------------|
| PID recovery running | The inverters perform PID recovery actively.                                                                         |
| PID abnormality      | It is detected that the ISO impedance is abnormal or the PID cannot work normally after the PID function is enabled. |

If the inverter is running abnormally, the alarm or fault icon  will be displayed in the lower right corner of the inverter icon in power flow chart. The user can tap this icon to enter the alarm or fault interface to view detailed information and corrective measures.

## 7.6 Run Information

Tap **Run Information** on the navigation bar to enter the screen showing running information, slide the screen upwards to view all detailed information.

Run information includes PV information, inverter information, input and output information, etc.

table 7-6 Run Information

| Classifica-<br>tion     | Parameter                       | Description                                                                       |
|-------------------------|---------------------------------|-----------------------------------------------------------------------------------|
| PV<br>Information       | String n Voltage                | The input voltage of the n <sup>th</sup> string                                   |
|                         | String n current                | The input current of the n <sup>th</sup> string                                   |
|                         | Running Status                  | /                                                                                 |
|                         | Total On-grid<br>Running        | /                                                                                 |
|                         | Daily On-grid Run-<br>ning Time | /                                                                                 |
| Inverter<br>Information | Negative Voltage to<br>Ground   | Inverter DC side negative to ground voltage value                                 |
|                         | Bus Voltage                     | Voltage between the positive and negative poles<br>of the DC side of the inverter |
|                         | Internal Air<br>Temperature     | /                                                                                 |
|                         | Array Insulation<br>Resistance  | Insulation resistance value of the input side to the<br>protection ground         |
|                         | Country Information             | /                                                                                 |
|                         | Power Limitation<br>Mode        | /                                                                                 |
|                         | Reactive Power<br>Mode          | /                                                                                 |
| Input                   | Total DC Power                  | DC side total input power                                                         |
|                         | MPPT x Voltage                  | The input voltage of the x <sup>th</sup> MPPT                                     |
|                         | MPPT x Current                  | The input current of the x <sup>th</sup> MPPT                                     |
| Output                  | Daily Yield                     | /                                                                                 |
|                         | Monthly Yield                   | /                                                                                 |
|                         | Annual Yield                    | /                                                                                 |
|                         | Total Yield                     | /                                                                                 |
|                         | Total Active Power              | Current active power value of the inverter                                        |
|                         | Total Reactive Power            | Current reactive power value of the inverter                                      |
|                         | Total Apparent<br>Power         | Current apparent power value of the inverter                                      |
|                         | Total Power Factor              | Power factor of the AC side of the inverter                                       |
|                         | Gird Frenquency                 | Frequency of the AC side of the inverter                                          |
|                         | A-B Line Voltage                | Line voltage                                                                      |
|                         | B-C Line Voltage                |                                                                                   |
|                         | C-A Line Voltage                |                                                                                   |

| Classification | Parameter       | Description   |
|----------------|-----------------|---------------|
|                | Phase A Current | Phase current |
|                | Phase B Current |               |
|                | Phase C Current |               |

## 7.7 Records

Tap **Records** on the navigation bar to enter the interface showing event records, as shown in the following figure.



figure 7-7 Records

### Fault Alarm Record

Tap **Fault Alarm Record** to enter the interface, as shown in the following figure.




figure 7-8 Fault Alarm Record



Tap  to select a time segment and view corresponding records.

The inverter can record up to 400 latest entries.

Select one of the records in the list and tap the record to view the detailed fault information as shown in following figure.





figure 7-9 Detailed Fault Alarm Information

### Yield Record

Tap **Yield Record** to enter the interface showing daily power generation as shown in the following figure.




figure 7-10 Power Curve

The App displays power generation records in a variety of forms, including daily power generation graph, monthly power generation histogram, annual power generation histogram.

table 7-7 Yield Record Explanation

| Parameter             | Description                                                                                                                                            |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Power curve           | Shows the power output from 5 am to 23 pm in a single day. Each point on the curve represents the percentage of present inverter power to rated power. |
| Daily yield histogram | Shows the power output every day in the present month.                                                                                                 |

| Parameter               | Description                                   |
|-------------------------|-----------------------------------------------|
| Monthly yield histogram | Shows the power output every month in a year. |
| Annual yield histogram  | Shows the power output every year.            |

Tap the time bar on the top of the interface to select a time segment and view the corresponding power curve.

Swipe left to check the power yields histogram.

### Event Record

Tap **Event Record** to view event record list.



Click to select a time segment and view corresponding records.

The inverter can record up to 400 latest entries.

## 7.8 More

Tap **More** on the navigation bar to enter the corresponding interface, as shown in the following figure.




figure 7-11 More

### 7.8.1 System Parameters

Tap “**Settings**→**System Parameters**” to enter the corresponding interface, as shown in the following figure.




figure 7-12 System Parameters

\* The image shown here is for reference only.

### Boot/Shutdown

Tap **Boot/Shutdown** to send the boot/shutdown instruction to the inverter.

### Date Setting/Time Setting

The correct system time is very important. Wrong system time will directly affect the data logging and power generation value. The clock is in 24-hour format.

### Software Version

Version information of the current firmware.

## 7.8.2 Operation Parameters

### Running Time

Tap “**Settings→Operation Parameters→Running Time**” to enter the corresponding interface.




figure 7-13 Running Time

### PID Parameters



The PID function may not be applicable in some areas. Please consult SUN-GROW for details.

Tap “**Settings→Operation Parameters→PID Parameters**” to enter the corresponding interface.




figure 7-14 PID Parameters

table 7-8 PID Parameter Description

| Parameter       | Description                                                                                                                                                                                                                                                                 |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PID Recovery    | Enable/Disable the PID night recovery function. Once enabled, it works between 22:00 pm and 5:00 am by default.                                                                                                                                                             |
| Clear PID alarm | If ISO impedance abnormality or PID function exception is detected during running of the PID function, the inverter reports a PID abnormality and reminds the user to take corresponding measures. Clear the alarm report via this parameter once the problems are handled. |
| PID Scheme      | Apply negative or positive voltage.                                                                                                                                                                                                                                         |

### AFCI Parameters



The AFCI function may not be applicable in some areas. Please consult SUN-GROW for details.

Tap "**Settings→Operation Parameters→AFCI Parameters**" to enter the corresponding screen, on which you can set "AFCI Parameters".




figure 7-15 AFCI Setting

### Regular Parameters

Tap "**Settings→Operation Parameters→Regular Parameters**" to enter the corresponding screen, on which you can set "Regular Parameters".




figure 7-16 Regular Parameters Setting

7.8.3 Power Regulation Parameters

Active Power Regulation

Tap “Settings→Power Regulation Parameters→Active Power Regulation” to enter the screen, as shown in the following figure.




figure 7-17 Active Power Regulation

table 7-9 Active Power Regulation

| Parameter                                | Definition/Setting Description                                                  | Range          |
|------------------------------------------|---------------------------------------------------------------------------------|----------------|
| Active power soft start after fault      | The switch for enabling/disabling the soft start function after a fault occurs. | Enable/Disable |
| Active power soft start time after fault | Time that the soft start takes to raise the power from 0 to 100% rated power.   | 1s~1200s       |

| Parameter                                     | Definition/Setting<br>Description                                                                                        | Range            |
|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|------------------|
| <b>Active power gradient control</b>          | Switch for enabling/disabling the active power rate settable function.                                                   | Enable/Disable   |
| <b>Active power decline gradient</b>          | The decline rate of inverter active power per minute.                                                                    | 1%/min~6000%/min |
| <b>Active power rising gradient</b>           | The rise rate of inverter active power per minute.                                                                       | 1%/min~6000%/min |
| <b>Active power setting persistence</b>       | Switch for enabling/disabling the function of saving output limited power.                                               | Enable/Disable   |
| <b>Active power limit</b>                     | The switch for limiting output power.                                                                                    | Enable/Disable   |
| <b>Active power limit ratio</b>               | The ratio of limiting output power to rated power in percentage.                                                         | 0%~110%          |
| <b>Shutdown when active power limit to 0%</b> | Switch used to determine whether the inverter is in stop state when the limited power reaches 0.                         | Enable/Disable   |
| <b>Active Overload Switch</b>                 | Switch used to ensure that the inverter operates at the maximum active power when PV power limit ratio is set over 100%. | Enable/Disable   |

### Reactive Power Regulation

Tap “**Settings→Power Regulation Parameters→Reactive Power Regulation**” to enter the screen, as shown in the following figure.




figure 7-18 Reactive Power Regulation

table 7-10 Reactive Power Regulation

| Parameter                          | Definition/Setting Description                                                | Range               |
|------------------------------------|-------------------------------------------------------------------------------|---------------------|
| Reactive power generation at night | Switch for enabling/disabling reactive power generation at night function.    | Enable/Disable      |
| Reactive power ratio at night      | Reactive power ratio set for the reactive power generation at night function. | -100%~0%/0%~100%    |
| Reactive power setting persistence | Switch for enabling/disabling the power-off function during reactive power.   | Enable/Disable      |
| Reactive power regulation mode     | —                                                                             | Off/PF/Qt/Q(P)/Q(U) |

The inverter provides the reactive power regulation function. Enable this function under "Reactive Power Regulation Mode" and select the appropriate mode.

table 7-11 Descriptions of reactive power regulation mode:

| Mode | Descriptions                                                              |
|------|---------------------------------------------------------------------------|
| Off  | The PF is fixed at +1.000.                                                |
| PF   | The reactive power can be regulated by the parameter PF (Power Factor).   |
| Qt   | The reactive power can be regulated by the parameter Q-Var limits (in %). |
| Q(P) | The PF changes with the output power of the inverter.                     |
| Q(U) | The reactive power changes with the grid voltage.                         |

**“Off” Mode**

The reactive power regulation function is disabled. The PF is limited to +1.000.

**“PF” Mode**

The power factor is fixed and reactive power setpoint is calculated according to the current power. The PF ranges from 0.8 leading to 0.8 lagging.

Leading: the inverter is sourcing reactive power to the grid.

Lagging: the inverter is injecting reactive power into the grid.

**“Qt” Mode**

In the Qt mode, system rated reactive power is fixed, and the system injects reactive power according to the delivered reactive power ratio. The **Reactive Power Ratio** is set through the App.

The setting range of the reactive power ratio is 0~100% or 0~-100%, corresponding to the ranges of inductive and capacitive reactive power regulation respectively.

**“Q(P)” Mode**

The PF of the inverter output varies in response to the output power of the inverter.

table 7-12 “Q(P)” Mode Parameter Descriptions:

| Parameter         | Explanation                                               | Range                                      |
|-------------------|-----------------------------------------------------------|--------------------------------------------|
| <b>Q(P) Curve</b> | Select corresponding curve according to local regulations | A, B, C*                                   |
| <b>QP_P1</b>      | Output power at P1 on the Q(P) mode curve (in percentage) | 0% ~ 100%                                  |
| <b>QP_P2</b>      | Output power at P2 on the Q(P) mode curve (in percentage) | 20% ~ 100%                                 |
| <b>QP_P3</b>      | Output power at P3 on the Q(P) mode curve (in percentage) | 20% ~ 100%                                 |
| <b>QP_K1</b>      | Power factor at P1 on the Q(P) mode curve                 | Curve A/C: 0.8 ~ 1<br>Curve B: - 0.6 ~ 0.6 |
| <b>QP_K2</b>      | Power factor at P2 on the Q(P) mode curve                 |                                            |
| <b>QP_K3</b>      | Power factor at P3 on the Q(P) mode curve                 |                                            |



| Parameter                  | Explanation                                             | Range       |
|----------------------------|---------------------------------------------------------|-------------|
| <b>QP_EnterVoltage</b>     | Voltage percentage for Q(P) function activation         | 100% ~ 110% |
| <b>QP_ExitVoltage</b>      | Voltage percentage for Q(P) function deactivation       | 90% ~ 100%  |
| <b>QP_ExitPower</b>        | Power percentage for Q(P) function deactivation         | 1% ~ 100%   |
| <b>QP_EnableMode</b>       | Unconditional activation/deactivation of Q (P) function | Yes / No    |
| <b>QU_Limited PF Value</b> | PF value for Q(U) function activation                   | 0~1         |

\* Curve C is reserved and consistent with Curve A currently.




figure 7-19 Q(P) Curve

table 7-13 "Q(U)" Mode Parameter Descriptions:

| Parameter               | Explanation                                               | Range       |
|-------------------------|-----------------------------------------------------------|-------------|
| <b>Q(U) curve</b>       | Select corresponding curve according to local regulations | A, B, C*    |
| <b>Hysteresis Ratio</b> | Voltage hysteresis ratio on the Q(U) mode curve           | 0 ~ 5%      |
| <b>QU_V1</b>            | Grid voltage limit at P1 on the Q(U) mode curve           | 80% ~ 100%  |
| <b>QU_Q1</b>            | Value of Q/Sn at P1 on the Q(U) mode curve                | -60% ~ 0    |
| <b>QU_V2</b>            | Grid voltage limit at P2 on the Q(U) mode curve           | 80% ~ 100%  |
| <b>QU_Q2</b>            | Value of Q/Sn at P2 on the Q(U) mode curve                | -60% ~ 60%  |
| <b>QU_V3</b>            | Grid voltage limit at P3 on the Q(U) mode curve           | 100% ~ 120% |
| <b>QU_Q3</b>            | Value of Q/Sn at P3 on the Q(U) mode curve                | -60% ~ 60%  |

| Parameter            | Explanation                                            | Range                         |
|----------------------|--------------------------------------------------------|-------------------------------|
| <b>QU_V4</b>         | Grid voltage limit at P4 on the Q(U) mode curve        | 100% ~ 120%                   |
| <b>QU_Q4</b>         | Value of Q/Sn at P4 on the Q(U) mode curve             | 0 ~ 60%                       |
| <b>QU_EnterPower</b> | Active power for Q(U) function activation              | 20% ~ 100%                    |
| <b>QU_ExitPower</b>  | Active power for Q(U) function deactivation            | 1% ~ 20%                      |
| <b>QU_EnableMode</b> | Unconditional activation/deactivation of Q(U) function | Yes / No / Yes, Limited by PF |

\* Curve C is reserved and consistent with Curve A currently.




figure 7-20 Q(U) Curve

## 7.8.4 Communication Parameters

Tap **Settings→Communication Parameters→Serial Port Parameters** to enter the corresponding interface, as shown in the following figure.

**SERIAL PORT PARAMETERS**

Device Address

1

figure 7-21 Serial Port Parameters

table 7-14 Serial Port Parameters

| Parameter      | Range |
|----------------|-------|
| Device Address | 1–246 |

## 7.8.5 Firmware Update


To avoid download failure due to poor on-site network signal, it is recommended to download the firmware package to the mobile device in advance.

**Step 1** Enable the "Mobile data" of the mobile device.

**Step 2** Open the App, enter the account and password on the login interface. Tap **Login** to enter the home interface.

**Step 3** Tap **"More→Firmware Download"** to enter corresponding interface on which you can view the device list.

**Step 4** Select the device model before downloading the firmware. Tap the device name in the device list to enter the firmware upgrade package detail interface, and tap  behind the firmware upgrade package to download it.



**Step 5** Return to the **Firmware Download** screen, tap  in the upper right corner of the interface to view the downloaded firmware upgrade package.


**Step 6** Login the App via local access. Refer to ["7.3 Login"](#).

**Step 7** Tap **More** on the App home page and then tap **Firmware Update**.

**Step 8** Tap the upgrade package file, a prompt box will pop up asking whether to upgrade the firmware with the file, tap **CONFIRM** to perform the firmware upgrade.



**Step 9** Wait for the file to be uploaded. When the upgrade is finished, a message is displayed indicating that the upgrade is completed. Tap **Complete** to end the upgrade.



-- End


## 7.8.6 Grounding Detection



Contact your distributor to obtain the advanced account and corresponding password before setting the earth detection parameters. If the distributor is unable to provide the required information, contact SUNGROW.

Unauthorized personnel are not allowed to log in with this account. Otherwise, SUNGROW shall not be held liable for any damages caused.

Tap **More**→**Settings**→**Operation Parameters**→**Grounding Detection** to enter the corresponding screen.




**figure 7-22** Grounding Detection

If the grounding detection is enabled, the DO relay will switch on automatically to signal the external alarm if the value exceeds the grounding detection alarm value.

The PV insulation resistance fault (fault sub-code 039) will trigger the DO relay to signal the external alarm.

### 7.8.7 Password Changing

Tap **Modify Password** to enter the modify password interface, as shown in the following figure.



**figure 7-23** Modify Password

The password shall consist of 8–20 digits, including letters and numbers.

## 8 System Decommissioning

### 8.1 Disconnecting Inverter

#### CAUTION

##### **Danger of burns!**

**Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.**

For maintenance or other service work, the inverter must be switched off.

Proceed as follows to disconnect the inverter from the AC and DC power sources. Lethal voltages or damage to the inverter will follow if otherwise.

**Step 1** Disconnect the external AC circuit breaker and prevent it from inadvertent reconnection.

**Step 2** Rotate the DC switch to the "OFF" position for disconnecting all of the PV string inputs.

**Step 3** Wait about 15 minutes until the capacitors inside the inverter completely discharge.

**Step 4** Ensure that the DC cable is current-free with a current clamp.

-- End

### 8.2 Dismantling the Inverter

#### CAUTION


##### **Risk of burn injuries and electric shock!**

**After the inverter is powered off for minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.**



- Before dismantling the inverter, disconnect the inverter from both AC and DC power sources.
- If there are more than two layers of inverter DC terminals, dismantle the outer DC connectors before dismantling the inner ones.
- If the original packing materials are available, put the inverter inside them and then seal them using adhesive tape. If the original packing materials are not available, put the inverter inside a cardboard box suitable for the weight and size of this inverter and seal it properly.

**Step 1** Refer to "[5 Electrical Connection](#)" to disconnect all cables in reverse steps. In particular, when removing the DC connector, use a connector wrench to loosen the locking parts and install waterproof plugs.



**Step 2** Refer to "[4 Mechanical Mounting](#)", to dismantle the inverter in reverse steps.

**Step 3** If necessary, remove the wall-mounting bracket from the wall.

**Step 4** If the inverter will be used again in the future, please refer to "[3.2 Inverter Storage](#)" for a proper conservation.

-- End

## 8.3 Disposal of Inverter

Users take the responsibility for the disposal of the inverter.

### WARNING

Please scrap the inverter in accordance with relevant local regulations and standards to avoid property losses or casualties.

### NOTICE

Some parts of the inverter may cause environmental pollution. Please dispose of them in accordance with the disposal regulations for electronic waste applicable at the installation site.

## 9 Troubleshooting and Maintenance

### 9.1 Troubleshooting

Once the inverter fails, the fault information is displayed on the App interface. If the inverter is equipped with an LCD screen, the fault information can be viewed on it.

The fault codes and troubleshooting methods of all PV inverters are detailed in the table below, and only some of the faults may occur to the model you purchased. When a fault occurs, you can check the fault information according to the fault code on the mobile app.

| Fault Code   | Fault Name        | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2, 3, 14, 15 | Grid Overvoltage  | <p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"><li>1. Measure the actual grid voltage, and contact the local electric power company for solutions if the grid voltage is higher than the set value.</li><li>2. Check whether the protection parameters are appropriately set via the App or the LCD. Modify the overvoltage protection values with the consent of the local electric power operator.</li><li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li></ol> |
| 4, 5         | Grid Undervoltage | <p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"><li>1. Measure the actual grid voltage, and contact the local electric power company for solutions if the grid voltage is lower than the set value.</li><li>2. Check whether the protection parameters are appropriately set via the App or the LCD.</li><li>3. Check whether the AC cable is firmly in place.</li><li>4. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li></ol>                                        |

| Fault Code | Fault Name             | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8          | Grid Overfrequency     | Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 9          | Grid Underfrequency    | <ol style="list-style-type: none"> <li>1. Measure the actual grid frequency, and contact the local electric power company for solutions if the grid frequency is beyond the set range.</li> <li>2. Check whether the protection parameters are appropriately set via the App or the LCD.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol>                                                                                                                                                                                                        |
| 10         | Grid Power Outage      | <p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Check whether the grid supplies power reliably.</li> <li>2. Check whether the AC cable is firmly in place.</li> <li>3. Check whether the AC cable is connected to the correct terminal (whether the live wire and the N wire are correctly in place).</li> <li>4. Check whether the AC circuit breaker is connected.</li> <li>5. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol> |
| 12         | Excess Leakage Current | <ol style="list-style-type: none"> <li>1. The fault can be caused by poor sunlight or damp environment, and generally the inverter will be reconnected to the grid after the environment is improved.</li> <li>2. If the environment is normal, check whether the AC and DC cables are well insulated.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol>                                                                                                                                                                                          |
| 13         | Grid Abnormal          | <p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Measure the actual grid, and contact the local electric power company for solutions if the grid parameter exceeds the set range.</li> <li>2. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol>                                                                                                                                                                                     |



| Fault Code                | Fault Name                  | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 17                        | Grid Voltage Imbalance      | <p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Measure the actual grid voltage. If grid phase voltages differ greatly, contact the electric power company for solutions.</li> <li>2. If the voltage difference between phases is within the permissible range of the local power company, modify the grid voltage imbalance parameter through the App or the LCD.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol> |
| 28, 29, 208, 212, 448-479 | PV Reserve Connection Fault | <ol style="list-style-type: none"> <li>1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the string current drops below 0.5 A.</li> <li>2. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol> <p>*The code 28 to code 29 are corresponding to PV1 to PV2 respectively.</p> <p>*The code 448 to code 479 are corresponding to string 1 to string 32 respectively.</p>                                                                                                            |
| 532-547, 564-579          | PV Reverse Connection Alarm | <ol style="list-style-type: none"> <li>1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the string current drops below 0.5 A.</li> <li>2. Contact Sungrow Customer Service if the preceding causes are ruled out and the alarm persists.</li> </ol> <p>*The code 532 to code 547 are corresponding to string 1 to string 16 respectively.</p> <p>*The code 564 to code 579 are corresponding to string 17 to string 32 respectively.</p>                                                                                              |

| Fault Code       | Fault Name                           | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------------|--------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 548-563, 580-595 | PV Abnormal Alarm                    | <p>Check whether the voltage and current of the inverter is abnormal to determine the cause of the alarm.</p> <ol style="list-style-type: none"> <li>1. Check whether the corresponding module is sheltered. If so, remove the shelter and ensure module cleanness.</li> <li>2. Check whether the battery board wiring is loose, if so, make it reliably connected.</li> <li>3. Check if the DC fuse is damaged. If so, replace the fuse.</li> <li>4. Contact Sungrow Customer Service if the preceding causes are ruled out and the alarm persists.</li> </ol> <p>*The code 548 to code 563 are corresponding to string 1 to string 16 respectively.</p> <p>*The code 580 to code 595 are corresponding to string 17 to string 32 respectively.</p> |
| 37               | Excessively High Ambient Temperature | <p>Generally, the inverter will resume operation when the internal or module temperature returns to normal. If the fault persists:</p> <ol style="list-style-type: none"> <li>1. Check whether the ambient temperature of the inverter is too high;</li> <li>2. Check whether the inverter is in a well-ventilated place;</li> <li>3. Check whether the inverter is exposed to direct sunlight. Shield it if so;</li> <li>4. Check whether the fan is running properly. Replace the fan if not;</li> <li>5. Contact Sungrow Power Customer Service if the fault is due to other causes and the fault persists.</li> </ol>                                                                                                                            |
| 43               | Excessively Low Ambient Temperature  | <p>Stop and disconnect the inverter. Restart the inverter when the ambient temperature rises within the operation temperature range.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

| Fault Code | Fault Name                                     | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------|------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 39         | Low System Insulation Resistance (Earth Fault) | <p>Wait for the inverter to return to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Check whether the ISO resistance protection value is excessively high via the app or the LCD, and ensure that it complies with the local regulations.</li> <li>2. Check the resistance to ground of the string and DC cable. Take corrective measures in case of short circuit or damaged insulation layer.</li> <li>3. If the cable is normal and the fault occurs on rainy days, check it again when the weather turns fine.</li> <li>4. If there are batteries, check whether battery cables are damaged and whether terminals are loose or in poor contact. If so, replace the damaged cable and secure terminals to ensure a reliable connection.</li> <li>5. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol> |
| 106        | Grounding Cable Fault                          | <ol style="list-style-type: none"> <li>1. Check whether the AC cable is correctly connected.</li> <li>2. Check whether the insulation between the ground cable and the live wire is normal.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 88         | Electric Arc Fault                             | <ol style="list-style-type: none"> <li>1. Disconnect the DC power supply, and check whether any DC cable is damaged, the connection terminal or fuse is loose or there is a weak contact. If so, replace the damaged cable, fasten the terminal or fuse, and replace the burnt component.</li> <li>2. After performing step 1, reconnect the DC power supply, and clear the electric arc fault via the App or the LCD, after that the inverter will return to normal.</li> <li>3. Contact Sungrow Customer Service if the fault persists.</li> </ol>                                                                                                                                                                                                                                                                                                                                                     |

| Fault Code | Fault Name                               | Corrective Measures                                                                                                                                                                                                                                                                                                                                  |
|------------|------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 84         | Reverse Connection Alarm of the Meter/CT | <ol style="list-style-type: none"> <li>1. Check if the meter is wrongly connected.</li> <li>2. Check if the input and output wiring of the meter is reversed.</li> <li>3. If the existing system is enabled, please check if the rated power setting of the existing inverter is correct.</li> </ol>                                                 |
| 514        | Meter Communication Abnormal Alarm       | <ol style="list-style-type: none"> <li>1. Check whether the communication cable and the terminals are abnormal. If so, correct them to ensure reliable connection.</li> <li>2. Reconnect the communication cable of the meter.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the alarm persists.</li> </ol> |
| 323        | Grid Confrontation                       | <ol style="list-style-type: none"> <li>1. Check whether the output port is connected to actual grid. Disconnect it from the grid if so.</li> <li>2. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol>                                                                                        |
| 75         | Inverter Parallel Communication Alarm    | <ol style="list-style-type: none"> <li>1. Check whether the communication cable and the terminals are abnormal. If so, correct them to ensure reliable connection.</li> <li>2. Reconnect the communication cable of the meter.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the alarm persists.</li> </ol> |

| Fault Code                                                                                                                                                                                                                                                                       | Fault Name              | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7, 11, 16, 19–<br>25, 30–34, 36,<br>38, 40–42, 44–<br>50, 52–58, 60–<br>69, 85, 87, 92,<br>93, 100–105,<br>107–114, 116–<br>124, 200–211,<br>248–255, 300–<br>322, 324–328,<br>401–412, 600–<br>603, 605, 608,<br>612, 616, 620,<br>622–624, 800,<br>802, 804, 807,<br>1096–1122 | System Fault            | <ol style="list-style-type: none"> <li>1. Wait for the inverter to return to normal.</li> <li>2. Disconnect the AC and DC switches, and disconnect the battery side switches if there are batteries. Close the AC and DC switches in turn 15 minutes later and restart the system.</li> <li>3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol>                    |
| 59, 70–74, 76–<br>83, 89, 216–<br>218, 220–233,<br>432–434, 500–<br>513, 515–518,<br>635–638, 900,<br>901, 910, 911,<br>996                                                                                                                                                      | System Alarm            | <ol style="list-style-type: none"> <li>1. The inverter can continue running.</li> <li>2. Check whether the related wiring and terminal are abnormal, check whether there are any foreign materials or other environmental abnormalities, and take corresponding corrective measures when necessary.</li> <li>3. If the fault persists, please contact Sungrow Power Customer Service.</li> </ol>                            |
| 264-283                                                                                                                                                                                                                                                                          | MPPT Reverse Connection | <ol style="list-style-type: none"> <li>1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the string current drops below 0.5 A.</li> <li>2. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.</li> </ol> <p>*The code 264 to code 279 are corresponding to string 1 to string 20 respectively.</p> |

| Fault Code | Fault Name                           | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------|--------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 332-363    | Boost Capacitor<br>Overvoltage Alarm | <p>1. The inverter can continue running.</p> <p>2. Check whether the related wiring and terminals are abnormal, check whether there are any foreign materials or other environmental abnormalities, and take corresponding corrective measures when necessary.</p> <p>If the fault persists, please contact Sungrow Power Customer Service.</p>                                                                                                                                                                                                 |
| 364-395    | Boost Capacitor<br>Overvoltage Fault | <p>1. Disconnect the AC and DC switches, and disconnect the battery side switches if there are batteries. Close the AC and DC switches in turn 15 minutes later and restart the system.</p> <p>2. If the fault persists, please contact Sungrow Power Customer Service.</p>                                                                                                                                                                                                                                                                     |
| 1548-1579  | String Current<br>Reflux             | <p>1. Check whether the number of PV modules of the corresponding string is less than other strings. If so, disconnect the DC switch and adjust the PV module configuration when the string current drops below 0.5 A.</p> <p>2. Check whether the PV module is shaded;</p> <p>3. Disconnect the DC switch to check whether the open circuit voltage is normal when the string current drops below 0.5 A. If so, check the wiring and configuration of the PV module,</p> <p>4. Check whether the orientation of the PV module is abnormal.</p> |

| Fault Code                  | Fault Name               | Corrective Measures                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1600 - 1615,<br>1632 - 1655 | PV Grounding<br>Fault    | <ol style="list-style-type: none"> <li>1. When the fault occurs, it is forbidden to directly disconnect the DC switch and unplug PV terminals when the direct current is greater than 0.5 A;</li> <li>2. Wait until the direct current of the inverter falls below 0.5 A, then disconnect the DC switch and unplug the faulty strings;</li> <li>3. Do not reinsert the faulty strings before the grounding fault is cleared;</li> <li>4. If the fault is not caused by the foregoing reasons and still exists, contact Sungrow Customer Service.</li> </ol> |
| 1616                        | System Hardware<br>Fault | <ol style="list-style-type: none"> <li>1. It is prohibited to disconnect the DC switch when the DC current is greater than 0.5 A when the fault occurs.</li> <li>2. Disconnect the DC switch only when the inverter DC side current drops below 0.5 A.</li> <li>3. It is prohibited to power up the inverter again. Please contact Sungrow Customer Service.</li> </ol>                                                                                                                                                                                     |



Contact the dealer if the measures listed in the “Troubleshooting Method” column have been taken but the problem persists. Contact SUNGROW if the dealer fails to solve the problem.

## 9.2 Maintenance

### 9.2.1 Maintenance Notices

#### DANGER

**Risk of inverter damage or personal injury due to incorrect service!**

- Be sure to use special insulation tools when perform high-voltage operations.
- Before maintenance, disconnect the AC circuit breaker on the grid side and then the DC switch. If a fault that may cause personal injury or device damage is found before maintenance, disconnect the AC circuit breaker and wait until the night before operating the DC switch. Otherwise, a fire inside the product or an explosion may occur, causing personal injuries.
- After the inverter is powered off for 15 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

#### DANGER

**When maintaining the product, it is strictly prohibited to open the product if there is an odor or smoke or if the product appearance is abnormal. If there is no odor, smoke, or obvious abnormal appearance, repair or restart the inverter according to the alarm corrective measures. Avoid standing directly in front of the inverter during maintenance.**

#### CAUTION

**To prevent misuse or accidents caused by unrelated personnel: Post prominent warning signs or demarcate safety warning areas around the inverter to prevent accidents caused by misuse.**

#### NOTICE

**Restart the inverter only after removing the fault that impairs safety performance. As the inverter contains no component parts that can be maintained, never open the enclosure, or replace any internal components.**

**To avoid the risk of electric shock, do not perform any other maintenance operations beyond this manual. If necessary, contact your distributor first. If the problem persists, contact SUNGROW. Otherwise, the losses caused is not covered by the warranty.**



**NOTICE**

Touching the PCB or other static sensitive components may cause damage to the device.

- Do not touch the circuit board unnecessarily.
- Observe the regulations to protect against electrostatic and wear an anti-static wrist strap.

**NOTICE**

If the earth fault occurs, the DO dry-contact will switch on automatically to signal the external alarm. The LED will turn red and a beeping sound will alarm until the fault is rectified, for internet connected products the error will also be sent to the portal.

### 9.2.2 Routine Maintenance

| Item                  | Method                                                                                                                                                                                                      | Period                                                               |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
| Device clean          | <p>Check whether the air outlet and heat sink are blocked by dust and other objects.</p> <p>Check if the air inlet and outlet are normal. Clean the air inlet and outlet, if necessary.</p>                 | <p>Six months to a year<br/>(depend on the dust contents in air)</p> |
| Fans                  | <p>Check whether there is a fan alarm on the App.</p> <p>Check whether there is any abnormal noise when the fan is rotating.</p> <p>Clean or replace the fans if necessary (see the following section).</p> | Once a year                                                          |
| Cable entry           | <p>Check whether the cable entry is insufficiently sealed or the gap is excessively large, and reseal the entry when necessary.</p>                                                                         | Once a year                                                          |
| Electrical connection | <p>Check whether cables are loose or fall off.</p> <p>Check whether the cable is damaged, especially the part in contact with the metal enclosure.</p>                                                      | Six months to a year                                                 |

### 9.2.3 Cleaning Air Inlet and Outlet

A significant amount of heat is generated when the inverter is working.

In order to maintain good ventilation, please check to make sure the air inlet and outlet are not blocked.

Clean the air inlet and outlet with soft brush or vacuum cleaner if necessary.

### 9.2.4 Fan Maintenance

#### **⚠ DANGER**


- **Power off the inverter and disconnect it from all power supplies before maintaining fans.**
- **After the inverter is powered off for 15 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.**
- **Fan maintenance must be performed by professionals.**

Fans inside the inverter are used to cool the inverter during operation. If the fans do not operate normally, the inverter may not be cooled down and inverter efficiency may decrease. Therefore, it is necessary to clean dirty fans and replace the broken fans in a timely manner.


The operation procedure is as follows:

**Step 1** Stop the inverter ( see"8.1 Disconnecting Inverter" )


**Step 2** Loosen the screw on the sealing plate of the fan module.



**Step 3** Press the tab of the latch hook, unplug the cable connection joint outwards, and loosen the screw on the fan holder.



**Step 4** Pull out the fan module, clean the fans with soft brush or vacuum cleaner, and replace them when necessary.



**Step 5** Reinstall the fan back to the inverter in reverse order and restart the inverter.

**-- End**

# 10 Appendix

## 10.1 Technical Data

| Parameters                                                 | SG25CX-<br>P2                   | SG30CX-<br>P2                | SG33CX-<br>P2 | SG36CX-<br>P2    | SG40CX-<br>P2 | SG50CX-<br>P2 |
|------------------------------------------------------------|---------------------------------|------------------------------|---------------|------------------|---------------|---------------|
| <b>Input (DC)</b>                                          |                                 |                              |               |                  |               |               |
| Recom-<br>mended<br>max. PV in-<br>put power               | 35 kWp                          | 42 kWp                       | 46.2 kWp      | 50.4 kWp         | 56 kWp        | 70 kWp        |
| Max. PV in-<br>put voltage                                 | 1100 V                          |                              |               |                  |               |               |
| Min. PV in-<br>put voltage /<br>Startup in-<br>put voltage | 160 V / 200 V                   |                              |               |                  |               |               |
| Rated PV<br>input<br>voltage                               | 600 V                           |                              |               |                  |               |               |
| MPP volt-<br>age range                                     | 160 V ~ 1000 V                  |                              |               |                  |               |               |
| MPP volt-<br>age range<br>for rated<br>power               | 400 V ~<br>800 V <sup>(1)</sup> | 500 V ~ 800 V <sup>(1)</sup> |               |                  |               |               |
| No. of inde-<br>pendent<br>MPP inputs                      | 3                               |                              | 4             |                  |               |               |
| No. of PV<br>strings per<br>MPPT                           | 2                               |                              | 2             |                  |               |               |
| Max. PV in-<br>put current                                 | 90 A (30 A * 3)                 |                              |               | 120 A (30 A * 4) |               |               |

| Parameters                       | SG25CX-<br>P2                        | SG30CX-<br>P2         | SG33CX-<br>P2    | SG36CX-<br>P2 | SG40CX-<br>P2 | SG50CX-<br>P2 |
|----------------------------------|--------------------------------------|-----------------------|------------------|---------------|---------------|---------------|
| Max. DC short-circuit current    | 120 A (40 A * 3)                     |                       | 160 A (40 A * 4) |               |               |               |
| Max. current for DC connector    | 20A <sup>(2)</sup>                   |                       |                  |               |               |               |
| Output (AC)                      |                                      |                       |                  |               |               |               |
| Rated AC output power            | 25 kW                                | 30 kW                 | 33 kW            | 36 kW         | 40 kW         | 50 kW         |
| Max. AC output power             | 27.5 kVA                             | 33 kVA <sub>(3)</sub> | 36.3 kVA         | 40 kVA        | 44 kVA        | 55 kVA        |
| Max. AC output current           | 41.8 A                               | 50.2 A                | 55.2 A           | 60.2 A        | 66.9 A        | 83.6 A        |
| Rated AC output current(at 230V) | 36.2 A                               | 43.5 A                | 47.8 A           | 52.17 A       | 58 A          | 72.5 A        |
| Rated AC voltage                 | 3 / N / PE, 220 / 380 V, 230 / 400 V |                       |                  |               |               |               |
| AC voltage range                 | 312 ~ 480 V                          |                       |                  |               |               |               |
| Rated grid frequency             | 50 Hz / 60 Hz                        |                       |                  |               |               |               |
| Grid frequency range             | 45 – 55 Hz / 55 – 65 Hz              |                       |                  |               |               |               |
| Harmonic (THD)                   | < 3 % (at Rated power)               |                       |                  |               |               |               |

| Parameters                                            | SG25CX-<br>P2                      | SG30CX-<br>P2 | SG33CX-<br>P2 | SG36CX-<br>P2 | SG40CX-<br>P2 | SG50CX-<br>P2 |
|-------------------------------------------------------|------------------------------------|---------------|---------------|---------------|---------------|---------------|
| Power factor at Rated power / Adjustable power factor | > 0.99 / 0.8 leading – 0.8 lagging |               |               |               |               |               |
| Feed-in phases / connection phases                    | 3 / 3-N-PE                         |               |               |               |               |               |
| Efficiency                                            |                                    |               |               |               |               |               |
| Max. efficiency / European efficiency                 | 98.4% / 98.2%                      | 98.5% / 98.3% |               |               |               |               |
| Protection                                            |                                    |               |               |               |               |               |
| Grid monitoring                                       | Yes                                |               |               |               |               |               |
| DC reverse connection protection                      | Yes                                |               |               |               |               |               |
| AC short-circuit protection                           | Yes                                |               |               |               |               |               |
| Leakage current protection                            | Yes                                |               |               |               |               |               |
| Surge protection                                      | DC Type I+II / AC Type II          |               |               |               |               |               |
| Ground fault monitoring                               | Yes                                |               |               |               |               |               |
| DC switch                                             | Yes                                |               |               |               |               |               |

| Parameters                                         | SG25CX-P2                | SG30CX-P2 | SG33CX-P2 | SG36CX-P2 | SG40CX-P2 | SG50CX-P2 |
|----------------------------------------------------|--------------------------|-----------|-----------|-----------|-----------|-----------|
| PV String current monitoring                       |                          |           |           | Yes       |           |           |
| Arc fault circuit interrupter (AFCI)               |                          |           |           | Yes       |           |           |
| PID recovery function                              |                          |           |           | Yes       |           |           |
| <b>General Data</b>                                |                          |           |           |           |           |           |
| Dimensions (W*H*D)                                 | 645*575*245 mm           |           |           |           |           |           |
| Mounting Method                                    | Wall-mounting bracket    |           |           |           |           |           |
| Weight                                             |                          | 38 kg     |           | 40 kg     | 40 kg     | 41 kg     |
| Topology                                           | Transformerless          |           |           |           |           |           |
| Degree of protection                               | IP66                     |           |           |           |           |           |
| Corrosion                                          | C5                       |           |           |           |           |           |
| Night power consumption                            | < 5 W                    |           |           |           |           |           |
| Operating ambient temperature range                | -30 to 60 °C             |           |           |           |           |           |
| Allowable relative humidity range (non-condensing) | 0 – 100 %                |           |           |           |           |           |
| Cooling method                                     | Smart forced air cooling |           |           |           |           |           |

| Parameters                                                                                                                                                                   | SG25CX-P2       | SG30CX-P2 | SG33CX-P2                 | SG36CX-P2                                                                                   | SG40CX-P2                         | SG50CX-P2                                  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------|---------------------------|---------------------------------------------------------------------------------------------|-----------------------------------|--------------------------------------------|
| Max. operating altitude                                                                                                                                                      |                 |           |                           | 4000 m                                                                                      |                                   |                                            |
| Display                                                                                                                                                                      |                 |           |                           | LED, Bluetooth+APP                                                                          |                                   |                                            |
| Communication                                                                                                                                                                |                 |           |                           | RS485 / Optional: WLAN, Ethernet                                                            |                                   |                                            |
| DC connection type                                                                                                                                                           |                 |           |                           | EVO2 (Max. 6 mm <sup>2</sup> )                                                              |                                   |                                            |
| AC connection type                                                                                                                                                           |                 |           |                           |                                                                                             |                                   | OT or DT terminal (35~50 mm <sup>2</sup> ) |
|                                                                                                                                                                              |                 |           |                           |                                                                                             |                                   | OT terminal (16~35 mm <sup>2</sup> )       |
| AC Cable specification                                                                                                                                                       |                 |           |                           | Outside diameter 18~38mm                                                                    |                                   |                                            |
| Grid Support                                                                                                                                                                 |                 |           |                           | Q at night function, LVRT, HVRT,active & reactive power control and power ramp rate control |                                   |                                            |
| Note(1):The voltage difference between MPPTs should be less than 80 V. The voltage of the configured string should be higher than the lower limit of the rated MPPT voltage. |                 |           |                           |                                                                                             |                                   |                                            |
| Note(2): 30A for India.                                                                                                                                                      |                 |           |                           |                                                                                             |                                   |                                            |
| Note(3): 30kVA for Germany, Belgium, Austria, Ukraine and Denmark, 33kVA for others.                                                                                         |                 |           |                           |                                                                                             |                                   |                                            |
| Parameters                                                                                                                                                                   | SG30CX-P2 ( 3 ) |           |                           | SG50CX-P2 ( 3 )                                                                             |                                   |                                            |
| Input (DC)                                                                                                                                                                   |                 |           |                           |                                                                                             |                                   |                                            |
| Recommended max. PV input power                                                                                                                                              |                 |           | 42 kWp                    |                                                                                             |                                   | 70 kWp                                     |
| Max. PV input voltage                                                                                                                                                        |                 |           |                           | 1100 V                                                                                      |                                   |                                            |
| Min. PV input voltage / Startup input voltage                                                                                                                                |                 |           |                           | 160 V / 200 V                                                                               |                                   |                                            |
| Rated PV input voltage                                                                                                                                                       |                 |           |                           | 600 V                                                                                       |                                   |                                            |
| MPP voltage range                                                                                                                                                            |                 |           |                           | 160 V - 1000 V                                                                              |                                   |                                            |
| MPP voltage range for rated power                                                                                                                                            |                 |           |                           | 500 V ~ 800 V <sup>(4)</sup>                                                                |                                   |                                            |
| No. of independent MPP inputs                                                                                                                                                |                 |           | 3                         |                                                                                             |                                   | 4                                          |
| No. of PV strings per MPPT                                                                                                                                                   |                 |           |                           | 2                                                                                           |                                   |                                            |
| Max. PV input current                                                                                                                                                        |                 |           | 90 A (30 A / 30 A / 30 A) |                                                                                             | 120 A (30 A / 30 A / 30 A / 30 A) |                                            |



| Parameters                                            | SG30CX-P2 ( 3 )                    | SG50CX-P2 ( 3 )                   |
|-------------------------------------------------------|------------------------------------|-----------------------------------|
| Max. DC short-circuit current                         | 120 A (40 A / 40 A / 40 A)         | 160 A (40 A / 40 A / 40 A / 40 A) |
| Output (AC)                                           |                                    |                                   |
| Rated AC output power                                 | 29.9 kW                            | 50 kW                             |
| Max. AC output apparent power                         | 29.9 kVA                           | 50 kVA                            |
| Rated AC output apparent power                        | 29.9 kVA                           | 50 kVA                            |
| Max. AC output current                                | 48.15 A                            | 80.5 A                            |
| Rated AC voltage                                      | 3 / N / PE, AC 230 / 400 V         |                                   |
| AC voltage range                                      | 312 - 480 V                        |                                   |
| Rated grid frequency / Grid frequency range           | 50 Hz / 45 – 55 Hz                 |                                   |
| Harmonic (THD)                                        | < 3 % (at rated power)             |                                   |
| Power factor at rated power / Adjustable power factor | > 0.99 / 0.8 leading – 0.8 lagging |                                   |
| Feed-in phases / connection phases                    | 3 / 3-N-PE                         |                                   |
| Efficiency                                            |                                    |                                   |
| Max. efficiency / European efficiency                 | 98.5% / 98.3%                      |                                   |
| Protection                                            |                                    |                                   |
| Grid monitoring                                       | Yes                                |                                   |
| DC reverse connection protection                      | Yes                                |                                   |
| AC short circuit protection                           | Yes                                |                                   |
| Leakage current protection                            | Yes                                |                                   |
| Surge protection                                      | DC Type I+II / AC Type II          |                                   |
| Ground fault monitoring                               | Yes                                |                                   |
| DC switch                                             | Yes                                |                                   |
| PV String current monitoring                          | Yes                                |                                   |
| Arc fault circuit interrupter (AFCI)                  | Yes                                |                                   |
| Protective Class                                      | I                                  |                                   |
| Overvoltage Category                                  | DC II / AC III                     |                                   |
| Active Anti-Islanding Method                          | Frequency Shift                    |                                   |
| General Data                                          |                                    |                                   |

| Parameters                                         | SG30CX-P2 ( 3 )                                                                              | SG50CX-P2 ( 3 )                            |
|----------------------------------------------------|----------------------------------------------------------------------------------------------|--------------------------------------------|
| Dimensions (W*H*D)                                 | 600*625*240 mm                                                                               |                                            |
| Weight                                             | 35 kg                                                                                        | 36 kg                                      |
| Topology                                           | Transformerless                                                                              |                                            |
| Degree of protection                               | IP66                                                                                         |                                            |
| Corrosion                                          | C5                                                                                           |                                            |
| Night power consumption                            | ≤5 W                                                                                         |                                            |
| Operating ambient temperature range                | -30 to 60 °C (> 45 °C derating)                                                              |                                            |
| Allowable relative humidity range (non-condensing) | 0 – 100 %                                                                                    |                                            |
| Cooling method                                     | Smart forced air cooling                                                                     |                                            |
| Max. operating altitude                            | 4000 m                                                                                       |                                            |
| Display                                            | LED, Bluetooth+APP                                                                           |                                            |
| Communication                                      | RS485 / WLAN / Ethernet, Optional: 4G                                                        |                                            |
| DC connection type                                 | Evo2 (Max. 6 mm <sup>2</sup> )                                                               |                                            |
| AC connection type                                 | OT terminal (16~35 mm <sup>2</sup> )                                                         | OT or DT terminal (35~50 mm <sup>2</sup> ) |
| AC Cable specification                             | Outside diameter 18~38mm                                                                     |                                            |
| Grid Support                                       | Q at night function, LVRT, HVRT, active & reactive power control and power ramp rate control |                                            |
| Country of manufacture                             | China                                                                                        |                                            |

Note(3):For Australia.

Note(4):The voltage difference between MPPTs should be less than 80 V. The voltage of the configured string should be higher than the lower limit of the rated MPPT voltage.

| Parameters                                                 | SG25CX-P2 <sup>(5)</sup> | SG30CX-P2 <sup>(5)</sup> | SG33CX-P2 <sup>(5)</sup> | SG36CX-P2 <sup>(5)</sup> | SG40CX-P2 <sup>(5)</sup> | SG50CX-P2 <sup>(5)</sup> |
|------------------------------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| <b>Input (DC)</b>                                          |                          |                          |                          |                          |                          |                          |
| Recom-<br>mended<br>max. PV in-<br>put power               | 35 kWp                   | 42 kWp                   | 46.2 kWp                 | 50.4 kWp                 | 56 kWp                   | 70 kWp                   |
| Max. PV in-<br>put voltage                                 | 1100 V                   |                          |                          |                          |                          |                          |
| Min. PV in-<br>put voltage /<br>Startup in-<br>put voltage | 160 V / 200 V            |                          |                          |                          |                          |                          |

| Parameters                        | SG25CX-<br>P2 <sup>(5)</sup> | SG30CX-<br>P2 <sup>(5)</sup> | SG33CX-<br>P2 <sup>(5)</sup> | SG36CX-<br>P2 <sup>(5)</sup> | SG40CX-<br>P2 <sup>(5)</sup> | SG50CX-<br>P2 <sup>(5)</sup> |
|-----------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|------------------------------|
| Rated PV input voltage            | 600 V                        |                              |                              |                              |                              |                              |
| MPP voltage range                 | 160 V ~ 1000 V               |                              |                              |                              |                              |                              |
| MPP voltage range for rated power | 400 V ~ 800 V <sup>(6)</sup> | 500 V ~ 800 V <sup>(6)</sup> |                              |                              |                              |                              |
| No. of independent MPP inputs     | 3                            |                              | 4                            |                              |                              |                              |
| No. of PV strings per MPPT        | 2                            |                              | 2                            |                              |                              |                              |
| Max. PV input current             | 90 A (30 A * 3)              |                              |                              | 120 A (30 A * 4)             |                              |                              |
| Max. DC short-circuit current     | 120 A (40 A * 3)             |                              |                              | 160 A (40 A * 4)             |                              |                              |
| Max. current for DC connector     | 20A                          |                              |                              |                              |                              |                              |
| Output (AC)                       |                              |                              |                              |                              |                              |                              |
| Rated AC output power             | 25 kW                        | 30 kW                        | 33 kW                        | 36 kW                        | 40 kW                        | 50 kW                        |
| Max. AC output power              | 27.5 kVA                     | 33 kVA <sup>(2)</sup>        | 36.3 kVA                     | 40 kVA                       | 44 kVA                       | 55 kVA                       |
| Max. AC output current            | 41.8 A                       | 50.2 A                       | 55.2 A                       | 60.2 A                       | 66.9 A                       | 83.6 A                       |

| Parameters                                                            | SG25CX-<br>P2(5)                     | SG30CX-<br>P2(5) | SG33CX-<br>P2(5) | SG36CX-<br>P2(5) | SG40CX-<br>P2(5) | SG50CX-<br>P2(5) |
|-----------------------------------------------------------------------|--------------------------------------|------------------|------------------|------------------|------------------|------------------|
| Rated AC<br>output cur-<br>rent(at<br>230V)                           | 36.2 A                               | 43.5 A           | 47.8 A           | 52.17 A          | 58 A             | 72.5 A           |
| Rated AC<br>voltage                                                   | 3 / N / PE, 220 / 380 V, 230 / 400 V |                  |                  |                  |                  |                  |
| AC voltage<br>range                                                   | 312 ~ 480 V                          |                  |                  |                  |                  |                  |
| Rated grid<br>frequency                                               | 50 Hz / 60 Hz                        |                  |                  |                  |                  |                  |
| Grid fre-<br>quency<br>range                                          | 45 – 55 Hz / 55 – 65 Hz              |                  |                  |                  |                  |                  |
| Harmonic<br>(THD)                                                     | < 3 % (at Rated power)               |                  |                  |                  |                  |                  |
| Power fac-<br>tor at Rated<br>power / Ad-<br>justable<br>power factor | > 0.99 / 0.8 leading – 0.8 lagging   |                  |                  |                  |                  |                  |
| Feed-in<br>phases /<br>connection<br>phases                           | 3 / 3-N-PE                           |                  |                  |                  |                  |                  |
| Efficiency                                                            |                                      |                  |                  |                  |                  |                  |
| Max. effi-<br>ciency /<br>European<br>efficiency                      | 98.4% /<br>98.2%                     |                  |                  | 98.5% / 98.3%    |                  |                  |
| Protection                                                            |                                      |                  |                  |                  |                  |                  |
| Grid<br>monitoring                                                    | Yes                                  |                  |                  |                  |                  |                  |

| Parameters                          | SG25CX-<br>P2(5) | SG30CX-<br>P2(5) | SG33CX-<br>P2(5)          | SG36CX-<br>P2(5) | SG40CX-<br>P2(5) | SG50CX-<br>P2(5) |
|-------------------------------------|------------------|------------------|---------------------------|------------------|------------------|------------------|
| DC re-verse con-nection pro-tection |                  |                  |                           | Yes              |                  |                  |
| AC short-circuit protection         |                  |                  |                           | Yes              |                  |                  |
| Leakage current protection          |                  |                  |                           | Yes              |                  |                  |
| Surge protection                    |                  |                  | DC Type I+II / AC Type II |                  |                  |                  |
| Ground fault monitoring             |                  |                  |                           | Yes              |                  |                  |
| DC switch                           |                  |                  |                           | Yes              |                  |                  |
| PV String current monitoring        |                  |                  |                           | Yes              |                  |                  |
| <b>General Data</b>                 |                  |                  |                           |                  |                  |                  |
| Dimensions (W*H*D)                  |                  |                  | 645*575*245 mm            |                  |                  |                  |
| Mounting Method                     |                  |                  | Wall-mounting bracket     |                  |                  |                  |
| Weight                              |                  | 38 kg            |                           | 40 kg            | 40 kg            | 41 kg            |
| Topology                            |                  |                  | Transformerless           |                  |                  |                  |
| Degree of protection                |                  |                  |                           | IP66             |                  |                  |
| Corrosion                           |                  |                  |                           | C5               |                  |                  |
| Operating ambient temperature range |                  |                  |                           | -30 to 60 °C     |                  |                  |

| Parameters                                         | SG25CX-<br>P2(5)                                                                             | SG30CX-<br>P2(5) | SG33CX-<br>P2(5) | SG36CX-<br>P2(5) | SG40CX-<br>P2(5) | SG50CX-<br>P2(5)                           |
|----------------------------------------------------|----------------------------------------------------------------------------------------------|------------------|------------------|------------------|------------------|--------------------------------------------|
| Allowable relative humidity range (non-condensing) | 0 – 100 %                                                                                    |                  |                  |                  |                  |                                            |
| Cooling method                                     | Smart forced air cooling                                                                     |                  |                  |                  |                  |                                            |
| Max. operating altitude                            | 4000 m                                                                                       |                  |                  |                  |                  |                                            |
| Display                                            | LED, Bluetooth+APP                                                                           |                  |                  |                  |                  |                                            |
| Communication                                      | RS485 / WLAN / Optional: Ethernet                                                            |                  |                  |                  |                  |                                            |
| DC connection type                                 | EVO2 (Max. 6 mm <sup>2</sup> )                                                               |                  |                  |                  |                  |                                            |
| AC connection type                                 | OT terminal (16~35 mm <sup>2</sup> )                                                         |                  |                  |                  |                  | OT or DT terminal (35~50 mm <sup>2</sup> ) |
| AC Cable specification                             | Outside diameter 18~38mm                                                                     |                  |                  |                  |                  |                                            |
| Grid Support                                       | Q at night function, LVRT, HVRT, active & reactive power control and power ramp rate control |                  |                  |                  |                  |                                            |

Note(5):For Latin America.

Note(6):The voltage difference between MPPTs should be less than 80 V. The voltage of the configured string should be higher than the lower limit of the rated MPPT voltage.

## 10.2 Wiring Distance of DI Dry Contact

The wiring distance between DI dry contact terminals must meet the requirements in the table below. The wiring distance L is the total length of all DI signal cables.

$$L = 2 \sum_{k=1}^n L_k$$

$L_k$  refers to the cable length in one direction between the DI dry contact terminal of the  $k^{\text{th}}$  inverter and the corresponding terminal of the  $(k-1)^{\text{th}}$  inverter.

table 10-1 Correspondence Between Inverter Quantity and Maximum Wiring Distance

| Number of Inverter | Maximum Wiring Distance(unit:m) |                              |
|--------------------|---------------------------------|------------------------------|
|                    | 16AWG / 1.31mm <sup>2</sup>     | 17AWG / 1.026mm <sup>2</sup> |
| 1                  | 13030                           | 10552                        |
| 2                  | 6515                            | 5276                         |
| 3                  | 4343                            | 3517                         |
| 4                  | 3258                            | 2638                         |
| 5                  | 2606                            | 2110                         |
| 6                  | 2172                            | 1759                         |
| 7                  | 1861                            | 1507                         |
| 8                  | 1629                            | 1319                         |
| 9                  | 1448                            | 1172                         |
| 10                 | 1303                            | 1055                         |
| 11                 | 1185                            | 959                          |
| 12                 | 1086                            | 879                          |
| 13                 | 1002                            | 812                          |
| 14                 | 931                             | 754                          |
| 15                 | 869                             | 703                          |
| 16                 | 814                             | 660                          |
| 17                 | 766                             | 621                          |
| 18                 | 724                             | 586                          |
| 19                 | 686                             | 555                          |
| 20                 | 652                             | 528                          |
| 21                 | 620                             | 502                          |
| 22                 | 592                             | 480                          |
| 23                 | 567                             | 459                          |
| 24                 | 543                             | 440                          |
| 25                 | 521                             | 422                          |

**NOTICE**

**In case the specification of the cable used is not included in the table above, when there is only one inverter, ensure that the line impedance of the input node is less than 300Ω; and when there are multiple inverters connected in the daisy chain, ensure that the impedance is less than 300Ω/number of inverter.**

## 10.3 Quality Assurance

When product faults occur during the warranty period, SUNGROW will provide free service or replace the product with a new one.

**Evidence**

During the warranty period, the customer shall provide the product purchase invoice and date. In addition, the trademark on the product shall be undamaged and legible. Otherwise, SUNGROW has the right to refuse to honor the quality guarantee.

**Conditions**

- After replacement, unqualified products shall be processed by SUNGROW.
- The customer shall give SUNGROW a reasonable period to repair the faulty device.

**Exclusion of Liability**

In the following circumstances, SUNGROW has the right to refuse to honor the quality guarantee:

- The free warranty period for the whole machine/components has expired.
- The device is damaged during transport.
- The device is incorrectly installed, refitted, or used.
- The device operates in harsh conditions beyond those described in this manual.
- The fault or damage is caused by installation, repairs, modification, or disassembly performed by a service provider or personnel not from SUNGROW.
- The fault or damage is caused by the use of non-standard or non-SUNGROW components or software.
- The installation and use range are beyond stipulations of relevant international standards.
- The damage is caused by unexpected natural factors.

For faulty products in any of above cases, if the customer requests maintenance, paid maintenance service may be provided based on the judgment of SUNGROW.

## 10.4 Contact Information

In case of questions about this product, please contact us.



We need the following information to provide you the best assistance:

- Model of the device
- Serial number of the device
- Fault code/name
- Brief description of the problem

For detailed contact information, please visit: <https://en.sungrowpower.com/contactUS>

**SUNGROW**

Sungrow Power Supply Co., Ltd.  
[www.sungrowpower.com](http://www.sungrowpower.com)